

AP722588-01 - Grimluck digital skipping rope

AP722588-01 - Grimluck digital skipping rope User manual



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specifications:

- LCD screen con 4 digits.
- Counter: Jumps, Distance in milles, Distance in kilometers, Calories burned.
- Battery LR44 included.

Operation:

Once you use the skipping rope the screen will turn on, showing the jumps made. Press again Mode button to change data showed between Distance in milles, Distance in kilometers, Calories burned in Kcal.

Press Reset button to reset all the counters to 0.

After 95 seconds without use the screen will turn o to save battery.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.



This symbol both in the product and its user manual indicates that at the end of the device's electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Distributor: Cool Collection, 1476 Budapest, POB. 176. Hungary
Registration number: 01-09-276783
Made in China



AP722588-01 - Grimluck digitális ugrálókötél Használati útmutató



Ajánlott a használati útmutató alapos elolvasása és későbbi hivatkozás céljából való megőrzése.

A termék áttekintése:



Specifikációk:

- 4 számjegyű LCD képernyő.
- Számláló: ugrások, távolság ezredben, távolság kilométerben, elégetett kalóriák.
- LR44 elemmel együtt.

Használat:

Az ugrálókötél használata után a képernyő bekapcsol, és az elvégzett ugrások láthatók. Nyomja meg újra az Üzem mód gombot a mutatott adatok módosításához: Távolság ezredben, Távolság kilométerben, Elégetett kalória Kcal-ban.

Nyomja meg a Reset gombot, hogy az összes számlálót 0-ra állítsa.

95 másodperc használat nélkül a képernyő kialszik az akkumulátor kímélése érdekében.

Figyelmeztetések:

1. Ne tegye ki az eszközt esőnek vagy nedves környezetnek
2. Akadályozza meg az eszköz leesését, mert súlyosan károsíthatja.
3. Az eszköz szétszereléséhez, javításához és módosításához kérje a szakember segítségét.
4. A kockázatok elkerülése érdekében csak erre kijelölt helyen dobja ki az eszközt
5. Az eszközt száraz ruhával tisztítsa.
6. Ne helyezze az eszközt hőforrások közelébe vagy tegye ki direkt napfénynek.



Ez a szimbólum azt jelenti, hogy az eszköz elektromos élettartamának lejártja után az Ön háztartási hulladékoktól elkülönítetten kell újrahasznosítani. Ennek megfelelően dobja a kijelölt hulladékgyűjtőbe. További információkért hívja a helyi hatóságokat

Forgalmazó: Cool Collection, 1476 Budapest, Pf. 176. Magyarország
Cégjegyzékszám: 01-09-276783
Számzási ország: Kína

