



## BACK PART

**AP722077 CRAPIN Hangszóró – használati utasítás (HUN)**




Javasoljuk, hogy figyelmesen olvassa el ezt a használati utasítást és tartsa meg a jövőbeli felhasználáshoz.

**Termék áttekintése:**




**Jellemzők:**  
5.0 bluetooth verzió  
Töltési feszültség: 5V  
300 mAh lítium akkumulátor 3,7V -  
Munkaidő: akár 3 óra  
Hatótávolság: akár 10 méter F-  
Frekvencia: 100Hz - 20KHz -  
Ellenállás: 4ohm  
Teljesítmény: 3W  
THD: <20%  
SNR: 70dB

**Beállítás:**

Nyomja hosszan a  gombot a hangszóró bekapcsolásához. A bluetooth jelzőlámpája elkezd villogni, ezzel jelzi, hogy az eszköz kész a párosításra.




Az Ön eszközének bluetooth menüjéből válassza ki az új eszközök közül a „6930”-at a párosításhoz. Amikor sikeresen megtörtént a párosítás, hallani fog egy értesítési hangot és a jelzőlámpa folyamatosan fog világítani.

Ha a  gombot hosszan nyomja, a hangszóró kikapcsol.

**Töltés:**

A töltéshez a mellékelt kábelt használja. Csatlakoztassa az USB kábelt a számítógéphez/AC adapterhez. Csatlakoztassa a kábel USB végét az Ön készülékének USB portjához. A töltés során a piros jelzőlámpa világít. Amikor a hangszóró teljesen feltöltődött, a piros lámpa kikapcsol.

**Ellenőrzések**


	a gombot röviden megnyomva a következő számrá ugrik hosszan nyomva a gombot a hangerőt növeli (ha elérte a max. hangerőt, hallani fog egy értesítési jelzést)
	a gombot röviden megnyomva az előző zeneszámrá ugrik. hosszan nyomva a gombot a hangerőt csökkenti (ha elérte a min. hangerőt, hallani fog egy értesítési jelzést)
	a gombot röviden megnyomva elindítja/megszakítja a zenét

**Hibaelhárítás:**


Hiba	Megoldás
Nem képes kapcsolódni más eszközzel	1. Ellenőrizze hogy a hangszóró még keresi a kapcsolatot vagy kapcsolja ki és be a készüléket. 2. Túl sok bluetooth eszköz van a közelben és ez okozza a problémát a kapcsolódásban. Kapcsolja ki a többi bluetooth eszközt 3. Ellenőrizze hogy az Ön fülhallgatója „kapcsolódási üzemmódban” van
A zene halk vagy toz	4. Ellenőrizze a bluetooth hangerőjének beállítását és állítsa be a megfelelő szintre. 5. Töltse fel az akkumulátort
Néha leáll a zene	6. Ellenőrizze le, hogy a hangszóró nem lépte túl a hatékony átviteli tartományt vagy nincs a hangszóró és a másik bluetooth eszköz között álló akadály

**Figyelmeztetések:**

- Ne tegye ki az eszközt esőnek vagy nyirkos környezetnek.
- Előzze meg, hogy az eszköz leessen, mert az komoly sérüléseket okozhat.
- Ne szedje szét, ne javítsa és ne alakítsa át az eszközt önállóan, lépjén kapcsolatba szakemberrel.
- Hogy minden kockázatot elkerüljön, ne dobja az eszközt helytelen szemetesbe, mert beépített lítium-akkumulátor van benne.
- Száraz ruhával takarítsa az eszközt.
- Ne tegye az eszközt közvetlen hőforrás mellé vagy közvetlen nap sugarzásnak.
- Ne tegyen semmiféle fém eszközt a készülékbe, mert rövidzárlatot okozhat.
- Gyermekek elől elzárva tartandó.


 Ez a szimbólum azt jelenti, hogy az eszköz elektronos élettartamának lejártja után az Ön háztartási hulladékaiként elkülönítetten kell újrahasznosítani. Ennek megfelelően dobja a kijelölt hulladékgyűjtőbe. További információkért hívja a helyi hatóságokat.

**Cikkszám: AP722077**  
**Forgalmazó: Cool collection, Budapest Pf.:176, 1476, Magyarország**  
**Cégjegyzékszám: 0108276783**  
**Százmaleszel ország: Kína**




## BACK PART

**AP722077\_Speaker Crapin User Manual (Eng)**




It is recommended to read this user manual carefully and keep it for future reference.

**Product Overview:**




**Specifications:**  
Bluetooth version 5.0  
Charging voltage: 5V  
Lithium battery 300mAh 3.7V  
Working Time: up to 3h  
Operating distance: up to 10 meters  
Frequency: 100Hz-20KHz  
Impedance: 4ohms  
Power output: 3W  
THD: <20%  
SNR: 70dB

**Operation:**

Long press  button to power on the speaker. The Bluetooth indicator light will start flashing to indicate that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select “6930” to pair. Once they are paired successfully, you will hear a notification sound and the lights will stay on.

Long press  button to power off the speaker.

**Charging:**

Use the cable provided for charging. Connect the USB cable to computer / AC adapter. Connect the micro USB end of this cable into the micro USB port of your device.




During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

**Charging:**

Use the cable provided for charging. Connect the USB cable to computer / AC adapter. Connect the micro USB end of this cable into the micro USB port of your device.

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

**Controls:**


	Short-press the button to next song. Long-press the button to increase the volume. (When maximum volume is reached, you will hear a notification sound)
	Short-press the button to previous song. Long-press the button to decrease the volume. (When minimum volume is reached, you will hear a notification sound)
	Short-press the button to play/pause the music.

**Troubleshooting**


Fault	Solution
Unable to pair up with other devices.	1. Check whether the speaker is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphone is in “Pairing Mode”.
The sound is low or distorted.	4. Check the Bluetooth device’s volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle standing between the speaker and other Bluetooth devices.

**Warnings:**

- Do not expose this product to rain or damp conditions.
- Prevent this item from falling as it could cause serious damage.
- Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
- In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.
- Clean the speaker with a dry cloth.
- Do not place this item near sources of heat or expose to direct sunlight.
- Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
- Keep out of reach of children.

 This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

**Cikkszám: AP722077**  
**Distributor: Cool Collection, Budapest POB.:176, 1476, Hungary**  
**Registration Nr.: 01-09-276783**

 **MADE IN PRC**