

AP722297_Krent bambusz képkeret

FRONT PART

AP722297_Krent bambusz képkeret Használati útmutató (Hun)



Javasoljuk, hogy figyelmesen olvassa el ezt a használati utasítást és tartsa meg a jövőbeli felhasználáshoz.

Termék nézet:



Jellemzők:

- Hőmérséklet tartomány (0-50 °C)
- Páratartalom tartomány (20-95%)
- Kizárólag beltéri használatra.
- 12/24h.

Működtetés:

Beállításokhoz lépésheznyomja meg a SET gombot 3 másodpercig míg a kijelző villogni kezd.

Nyomja a ⌚ vagy ⌚ gombot, hogy beállítsa az órát.

Nyomja a MODE gombot újra, hogy változtassa a percet e

⌚ ⌚ gombok nyomásával. Nyomja a mód gombot, a befejezéshez.

Nyomja a ⌚ gombot a főmenüből, hogy változtassa az óra formátumát (12/24 óra).

Figyelmeztetés:

1. Ne tegye ki az eszközt esőnek vagy nyirkos környezetnek.
2. Előzze meg, hogy az eszköz leessen, mert az komoly sérüléseket okozhat.
3. Ne szedje szét, ne javítsa és ne alakítsa át az eszközt önállóan, lépjen kapcsolatba szakemberrel.
4. Hogy minden kockázatot elkerüljön, ne dobja az eszközt helytelen szemétesbe.
5. Száraz ruhával takarítsa az eszközt.
6. Ne tegye az eszközt közvetlen hőforrás mellé vagy közvetlen napsugárzásnak.
7. Ne tegyen semmiféle fém eszközt a készülékbe, mert rövidzárlatot okozhat.



Ez a szimbólum azt jelenti, hogy az eszköz elektromos élettartamának lejáta után az Ön háztartási hulladékatól elkülönítetten kell újrahasznosítani. Ennek megfelelően dobja a kijelölt hulladékgyűjtőbe. További információkért hívja a helyi hatóságokat.

Cikkszám: AP722297
Forgalmazó: Cool collection, Budapest Pf.:176,
1476, Magyarország
Cégjegyzékszám: 01-09-216783
Szármasási ország: Kína

BACK PART

AP722297_Photo Frame Weather Station Krent User manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specifcations:

- Temperature range (0-50 °C)
- Humidity range (20-95%)
- For interior use only
- 12/24h.

Operation:

To enter setting mode, press the SET button for 3 seconds until the screen starts to flash.

Press ⌚ or ⌚ to adjust the hour.

Press MODE button again to change minutes and press ⌚ or ⌚ to modify them. Press MODE to finish.

Press ⌚ button from main menu to change the hour format (12/24horas).

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Item number: AP722297
Distributor: Cool collection, Budapest Pf.:176, 1476, Hungary
Registration number: 01-09-216783
Country of origin: China