

AP721290_Milcof Speakers Headphones /Milcof fejhallgató

AP721290_Speakers Headphones Milcof User Manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product Overview:



Specifications:

- Bluetooth Version 4.2
- Hadphones Output: 10mW
- Speaker Power: 3W x 2
- Operating distance: up to 10 meters
- Frequency: 2.4-2.48GHz
- SNR: 90dB
- Impedance: 32ohms
- THD: 1%
- Lithium battery 500mAh, 3.7V
- Working time of headphone: up to 10h
- Working time of speaker: up to 2.5h
- FM Radio: 87-108MHz
- Micro SD Card: Up to 32GB
- Supported Audio Format: MP3/WMA/ASF

Charging:

Use the cable provided for charging. Connect USB cable to computer / AC adapter. Connect the micro USB end of this cable into the micro USB port of your device.

During charging, the indicator light will turn red. When the headphones are fully charged the red indicator light will turn off.

IMPORTANT: Charge the device when it is turned off.

Operation:

Hold the  button to power on the headphones. The green and blue indicator light will flash to indicate that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "6131" to pair. Once they are paired successfully, the blue indicator light will stay on.

Hold the  button to power off the headphones.

Micro SD Card:

When you insert a micro SD card into the micro SD slot, the music will automatically start playing.

Audio Input (Line in):

Insert the audio cable 3.5mm into the headphones, and connect the other end of the audio cable into your mp3 / mp4 player / mobile phone or other compatible device to play your music.

Note: To use this function, the headphones must be turned off.

FM Radio

In radio mode, press  and the headphones will automatically search for radio channels. Press  V+ and  V- to change the channel.

Note: If there is no radio channel programmed you will hear a hiss sound.

Speaker/Headphones:

Slide the button to the speaker/headphones position, as desired.

For better sound quality, using the speaker function, turn the headphones as shown in the picture.



Controls:

M	• Short-press to change the function. (Bluetooth / FM Radio / Micro SD Card)
 V+	• Short-press the button to next song. • Long-press the button to increase the volume. (When maximum volume is reached, you will hear a notification sound)
 V-	• Short-press the button to previous song. • Long-press the button to decrease the volume. (When minimum volume is reached, you will hear a notification sound)
	• Short-press the button to answer/end a call. • Short-press the button to play/pause the music. • Long press the button to reject an incoming call. • Press the button twice to redial the last outgoing phone number.

Troubleshooting:

Fault	Solutions
Unable to pair up with other devices.	1. Check whether the headphones are still on the process of search or switch them off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your headphones are in "Pairing Mode".
The sound is low or distorted.	4. Check the Bluetooth device's volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the headphones effective transmission range is exceeded or if there is an obstacle standing between the headphones and other Bluetooth devices.

Warnings:

- Do not expose this product to rain or damp conditions.
- Prevent this item from falling as it could cause serious damage.
- Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
- In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
- Clean with a dry cloth.
- Do not place this item near sources of heat or expose to direct sunlight.
- Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
- Excessive sound pressure from earphones and headphones can cause hearing loss.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

CE
MADE IN PRC

Distributor: Cool Collection, 1476, Budapest, POB:176. Hungary
Registration nr.: 01-09-276783, Made in China

AP721290_Milcof fejhallgató



Javasoljuk, hogy alaposan olvassa el a használati útmutatót és őrizze meg későbbi felhasználás céljából.

Termék áttekintés:



Technikai adatok:

- 4.2 + EDR Bluetooth
- 10mW kimenet
- Hatótávolság: akár 10 méter
- Frekvencia: 2,4-2,48GHz
- Hangerő: 105dB
- Ellenállás: 32 Ohm
- Torzítás: kevesebb mint 1%
- Litium akkumulátor 450mAh
- Bemenet: 3,7V
- Működési időtartam: 10 óra
- Készenléti idő: 180 óra
- Rádió frekvencia: 87-108M HZ
- Bővíthető Mikro USB kártyával akár 32 GB-ig
- 3.5 mm Jack audió kábel

Töltés:

Töltés esetén használja a termékhez mellékelt kábelt. Csatlakoztassa az USB kábelt a számítógéphez / AC adapterhez. Csatlakoztassa a kábel Mikro USB végét a készülékének Mikro USB portjához.

A töltés alatt a jelzőfény pirosra vált. Teljesen feltöltött állapotban a piros jelzőfény kékre vált.

Működés:

Tartsa lenyomva a bekapcsoló gombot a fejhallgató bekapcsolásához. A kék és piros fény kivillanása jelzi, ha az eszköz kész a párosításra.

Az eszköz Bluetooth menüjében keressen új eszközöket és válassza a(z) "5945"-t a párosításhoz. Amint sikeres a csatlakozás, a jelzőfény folyamatosan kéken fog világítani. A visszajelző fények villogni fognak néhány funkció használata közben.

Tartsa lenyomva a bekapcsoló gombot a készülék kikapcsolásához.

Mikro SD kártya

Amikor behelyezi a USB kártyát a Micro USB olvasóba a fejhallgatóban a zene automatikusan elindul.

Hang bemenet

Dugja be az audiókábelt a 3,5mm-es fejhallgatóba és csatlakoztassa az audiókábel másik végét az MP3/ MP4 lejátszóhoz/ mobilkészülékhez vagy más kompatibilis eszközhez a zene lejátszásához.

Megjegyzés: Ez a funkció akkor is működik, ha a fejhallgató be vagy ki van kapcsolva. Ha a kábelt csatlakoztatja, a fejhallgató automatikusan kikapcsol, de a zene továbbra is menni fog, ha csatlakoztatta az eszközhez.

FM rádió

Rádió üzemmódban nyomja meg az M gombot és a fejhallgató automatikusan megkeresi a rádió csatornákat. Nyomja meg jobbra-Balra gombot a zeneváltáshoz.

Megjegyzés: Ha nincs rádiócsatorna programozva, akkor segíséget fog hallani.

Hangszóró/Fejhallgató:

Állítsa be igény szerint a gombot a hangszóró/ fejhallgató módba. A jobb hangminőség érdekében a hangszóró funkció használatával fordítsa el a fejhallgatót a képen látható módon



Működtetés:

M	-Nyomja meg röviden a funkció mód kiválasztásához (Bluetooth, FM rádió/ Mikro SD kártya)
 V+	-Nyomja meg röviden a gombot a következő szám kiválasztásához. -Nyomja meg hosszan a gombot a hangerő növeléséhez. (egy hang fogja jelezni a maximális hangerőt)
 V-	-Nyomja meg röviden a gombot az előző zeneszámmhoz. -Nyomja meg hosszan a gombot a hangerő csökkentéséhez. (egy hang fogja jelezni a minimális hangerőt)
	-Nyomja meg röviden a gombot bejövő hívás fogadásához. -Nyomja meg röviden a gombot a zene lejátszásához / szüneteltetéséhez. -Nyomja meg hosszan a gombot bejövő hívás elutasításához. -Nyomja meg kétszer a gombot az utolsó kimenő hívás újratárcsázásához.

Hibaelhárítás

Hiba	Megoldás
Nem tud kapcsolódni más eszközökhöz	1. Ellenőrizze, hogy a fejhallgató még mindig keresi-e a készüléket, vagy kapcsolja ki és újra be. 2. Problémát okozhat a csatlakozásban, ha több Bluetooth eszköz található a közelben. Kapcsolja ki a többi Bluetooth eszközt. 3. Bizonyosodjon meg arról, hogy az eszköz "csatlakozási módban" van
A hang halk vagy torz.	4. Ellenőrizze a Bluetooth eszközön a hangerőt, majd állítsa be a kívánt szintre. 5. Töltsse fel az akkumulátort.
Időnként a zene megáll.	6. Ellenőrizze, hogy töllepte-e a fejhallgató tényleges átviteli tartományját, illetve, hogy van-e akadály a fejhallgató és más Bluetooth-eszközök között.

Figyelmeztetés:

- Ne tegye ki a terméket esőnek vagy páras körülményeknek.
- Akadályozza meg a termék leesését, mivel az komoly kárral járhat.
- Ne szedje szét, javítsa-vagy módosítsa az eszközt önmagától, keressen fel egy szakembert.
- A kockázat elkerülése érdekében a kijelölt helyekre dobja ki a terméket, illetve semmiképp se dobja tűzbe, mivel beépített lítium akkumulátor van benne.
- Száraz törölkendővel tisztítsa.
- Ne tegye hőforrások közelébe és ne tegye ki közvetlen napfénynek a készüléket.
- Ne helyezzen semmilyen fém tárgyat a készülékbe, mert fennáll annak a veszélye, hogy rövidzárlat keletkezik az egységben.
- A fül- és fejhallgató túl magas hangerőn való hallgatása halláskárosodást okozhat.



Ez a szimbólum a termék csomagolásán és a használati útmutatóján jelzi, hogy a készülék élettartama lejártá után a szelektív gyűjtőbe kerüljön elkülönítve a háztartási hulladéktól. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információkért keresse a helyi hatóságot.

CE
MADE IN PRC

Forgalmazó: Cool Collection, 1476, Budapest, Pf:176, Magyarország
Cégjegyzékszám: 01-09-276783, Származási ország: Kína