

AP741951 Speaker Martins User Manual



It is recommended to read this user manual carefully and keep it for future reference.

Product Overview:



1. Controls
2. Main Switch
3. Indicator light
4. Micro SD Card Slot
5. Charging Input
6. Microphone

Specifications:

- Bluetooth version 5.0
- Charging voltage: 5V
- Lithium battery 300mAh 3.7V
- Working Time: up to 3h
- Operating distance: up to 10 meters
- Frequency: 280Hz-16KHz
- Impedance: 4ohms
- Power output: 3W
- THD: less than 5%
- SNR: 95dB +/- 2dB
- Micro SD card: up to 32GB

Operation:

Move the main switch to \times position to power on the speaker. The indicator light will start flashing to indicate that the device is ready to be paired.

Move the main switch to "OFF" position to power off the speaker .

Playing Music via Bluetooth:

From the Bluetooth menu of your device, search for new devices and select "4936" to pair. Once they are paired successfully, you will hear a notification sound and the light will stay on.

Playing Music via Micro SD Card:

When you insert a micro SD card into the micro SD card slot, the music will automatically start playing.

Audio Input (AUX):

Insert the Micro USB cable into the Micro USB port, and insert the 3.5mm jack into your mp3/mp4 player/mobile phone or other compatible device to play the music.

FM Radio:

Connect the Micro USB cable into the Micro USB port to work as an antenna. Move the main switch to the MP3 position. Short press \blacktriangleright and the speaker will automatically search for radio channels.

Short press $\blacktriangleleft/\text{—}$ or \blacktriangleright to change the channel.

Charging:

Use the cable provided for charging. Connect the USB cable to computer / AC adapter. Connect the Micro USB end of this cable into the Micro USB port of your device.

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off .

Controls:

$\blacktriangleright/\blacktriangleright\blacktriangleright$	<ul style="list-style-type: none"> • Short-press the button to next song. • Long-press the button to increase the volume.(When maximum volume is reached, you will hear a notification sound)
$\blacktriangleleft/\text{—}$	<ul style="list-style-type: none"> • Short-press the button to previous song. • Long-press the button to decrease the volume.
$\blacktriangleright\ $	<ul style="list-style-type: none"> • Short-press the button to answer/end a call. • Short-press the button to play/pause the music. • Long press the button to reject an incoming call. • Short press twice consecutively to redial the last phone number.
\times OFF MP3	<ul style="list-style-type: none"> • Switch to change the function (Bluetooth / FM Radio / Micro SD card / USB flash drive / Aux Mode).

Troubleshooting:

Fault	Solution
Unable to pair with other devices.	<ol style="list-style-type: none"> 1. Check whether the speaker is still in the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your device is in "Pairing Mode".
The sound is low or distorted.	<ol style="list-style-type: none"> 4. Check the Bluetooth device volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	<ol style="list-style-type: none"> 6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.

4. In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children.

This item is in conformity with the following standards:

RoHS Directive 2011/65/EU (RoHS 2.0) and its subsequent amendments Directive (EU) 2015/863
Radio Equipment Directive (RED) - Directive 2014/53/EU

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.



Distributor: Cool Collection,
1476 Budapest, POB: 176, Hungary
Registration nr.: 01-09-276783
Made in China

AP741951 Martins hangszóró Használati útmutató



Ajánlott a használati utasítás alapos elolvasása és megőrzése.

A termék áttekintése



1. Irányítógombok
2. Főkapcsoló
3. Jelzőfény
4. Mikro SD kártya helye
5. Töltő bemenet
6. Mikrofon

Specifikációk:

- Bluetooth verzió 5.0
- Töltési feszültség 5V
- Litium akkumulátor 300mAh 3.7V
- Üzemidő: up to 3h
- Működési távolság: 10 méterig
- Frekvencia: 280Hz-16KHz
- Impedancia: 4 Ohm
- Kimeneti teljesítmény: 3W
- THD: kevesebb mint 5%
- SNR: 95dB +/- 2dB
- Mikro SD kártya: 32GB-ig

Használat:

Állítsa a főkapcsolót \times helyzetbe a hangszóró bekapcsolásához. A jelzőfény villogással jelzi, hogy az eszköz készen áll a párosításra.

Állítsa a főkapcsolót "OFF" helyzetbe a hangszóró kikapcsolásához.

Zene lejátszása Bluetooth segítségével:

Eszköze Bluetooth menüjében keressen új eszközöket, és válassza ki a "4936"-ot párosításra. A sikeres párosításkor jelzőhangot fog hallani, és a jelzőfény égvé marad.

Zene lejátszása Mikro SD kártyával:

Amikor behelyezi a mikro SD kártyát, a zene lejátszása automatikusan megkezdődik.

Audio bemenet (AUX):

Helyezze a mikro USB kábelt a mikro USB csatlakozóba, és dugja a 3.5mm-es jack csatlakozót az mp3/mp4 lejátszója/mobiltelefonjába vagy más kompatibilis eszközébe a zene lejátszásához.

FM Rádió:

Csatlakoztassa a mikro USB kábelt a mikro USB csatlakozóba, hogy antennaként funkcionáljon. Állítsa a főkapcsolót MP3 helyzetbe. Nyomja meg röviden a $\blacktriangleright\parallel$ gombot, és a hangszóró automatikusan elkezd rádió csatornákat keresni. Nyomja meg röviden a $\blacktriangleleft/\text{---}$ vagy $\blacktriangleright/\blacktriangleright\parallel$ gombot a csatornák közötti váltáshoz.

Töltés:

Használja a csomagban található kábelt a töltéshez. Csatlakoztassa az USB kábelt számítógéphez vagy AC adapterhez. Helyezze a kábel Mikro USB végét az eszköze Mikro USB csatlakozójába.

A töltés ideje alatt piros jelzőfény fog világítani. A hangszóró teljes feltöltöttségének elérésekor a jelzőfény kialszik.

Irányítás:

$\blacktriangleright/\blacktriangleright\parallel$	<ul style="list-style-type: none">• Nyomja le röviden a gombot a következő dalra váltáshoz.• Nyomja le hosszan a hangerő növeléséhez. (A maximum hangerő elérésekor jelzőhangot fog hallani.)
$\blacktriangleleft/\text{---}$	<ul style="list-style-type: none">• Nyomja le röviden a gombot a az eggyel korábbi dalra váltáshoz.• Nyomja le hosszan a gombot a hangerő csökkentéséhez.
$\blacktriangleright\parallel$	<ul style="list-style-type: none">• Nyomja le röviden hívások fogadásához/ befejezéséhez• Nyomja le röviden a zene elindításához/ szüneteléséhez.• Nyomja le hosszan bejövő hívás elutasításához.• Nyomja le kétszer egymás után röviden az utolsó telefonszám újratárcsázásához.
\times OFF MP3	<ul style="list-style-type: none">• Váltson a működési mód megváltoztatásához. (Bluetooth / FM Rádió / Mikro SD kártya / USB flash drive / Aux mód).

Hibaelhárítás:

Hiba	Megoldás
Sikertelen párosítás más eszközökkel	<ol style="list-style-type: none">1. Ellenőrizze, hogy nem tart-e még a keresés, vagy kapcsolja ki majd újra be a hangszórót.2. Lehetőség, hogy túl sok Bluetooth eszköz van a közelben, ami megnehezíti a csatlakozást. Kapcsolja ki a többi Bluetooth eszközt.3. Bizonyosodjon meg róla, hogy az eszköz "Pairing Mode"-ban van.
A hangerő túl alacsony vagy a hang torzul.	<ol style="list-style-type: none">4. Ellenőrizze Bluetooth eszköze hangerőjét és állítsa megfelelő szintre.5. Töltse fel az akkumulátort.
A zene időnként leáll.	<ol style="list-style-type: none">6. Ellenőrizze, hogy nem lépte-e túl az eszköz használati távolságát vagy nincs-e akadály a hangszóró és a kihangosítási próbált eszköz között.

Figyelmeztetések:

1. Ne tegye ki az eszközt esőnek vagy nedves környezetnek.
2. Kerülje el az eszköz leesését, mivel komoly kárt tehet benne. Ne szedje szét, javítsa vagy módosítsa maga az eszközt, kérje szakember segítségét.

4. A kockázatok elkerülése érdekében a terméket csak erre kijelölt helyre dobja ki, mivel beépített Litium akkumulátort tartalmaz.
5. A hangszórót száraz ruhával tisztítsa.
6. Ne helyezze az eszközt hőforrások közelébe, és ne tegye ki közvetlen napfénynek.
7. Ne helyezzen semmilyen fém tárgyat az eszközbe, mivel rövidzárlatot okozhat az egységben.
8. Gyermekektől távol tartandó.

Ez a termék az alábbi irányelveknek felel meg:

RoHS 2.0 2011/65/EU irányelv és későbbi módosításai (EU) 2015/863 Rádióberendezésekről szóló irányelv (RED) – 2014/53/EU

VIGYÁZAT: Nem megfelelő elem használata esetén robbanásveszély áll fenn. Az elhasznált elemeket az utasításoknak megfelelően ártalmatlanítsa.



Ez a szimbólum a termék csomagolásán és a használati útmutatón jelzi, hogy a készülék élettartama lejártá után a szelektív gyűjtőbe kerüljön elkülönítve a háztartási hulladéktól. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információkért keresse a helyi hatóságot.



Forgalmazó: Cool Collection,
1476 Budapest, Pf. 176. Magyarország
Cégjegyzékszám: 01-09-276783
Szarmazási ország: Kína