

**AP806904 Loris pen holder  
User Manual**

**Features:**

- Year, month and day displays from 1 January 1900 up to 31 December 2099
- Time display
- Temperature display from -9 °C to +59 °C (16 °F to 138 °F)
- Daily alarm (two minutes duration) with Snooze function
- Countdown timer (23 hours 59 minutes)
- Birthday reminder alarm
- Includes eight popular international musical tunes
- „Λ”, „V” buttons to facilitate selection operation
- Low 3 V electrical consumption. Low power consumption

**Modes of Operation**

Function buttons: MODE (⌚), ALARM (🔔), (SET), UP (Λ), DOWN (V)

1. (⌚) button: Used to select the following functions cyclically: Time Setting – Alarm – Birthday Reminder – Countdown Timer – Normal Mode
2. (🔔) button: Alarm will beep for two minutes at the set time when alarm is on. Press (🔔) button to stop beeping.
3. (SET) button:
  - (1) In SET Mode use the (SET) button to change the selected entry. (i.e. hour, minute, year and month)
  - (2) In Normal Mode press the (SET) button to switch between °C and °F temperature readings.
  - (3) Press the (⌚) button to select the timer countdown mode: press the (SET) button to begin timer countdown
4. (Λ) button
  - (1) In SET Mode press (Λ) to increase the value of current setting.
  - (2) In Normal Mode press (Λ) to turn Snooze on or off.
5. (V) button
  - (1) In SET Mode press (V) to decrease the value of the current setting.
  - (2) In Normal Mode press (V) to turn music on or off.

**Description of Operations**

**Time Setting**

Press the (⌚) to set time. The hour display will begin to flash. Press the (SET) button to select minute, year, month or day. Use the (Λ) or (V) button to adjust current settings.

**Alarm Setting**

Press the (⌚) button to set the alarm. Press the (SET) button, the hour display will begin to flash. Press the (SET) button again to change the minute setting. Use the (Λ) or (V) button to change current settings. After the changes are complete, press the (SET) button to turn alarm function on or off. When alarm function is on, a „🔔” (bell) will be displayed on the LCD screen.

**Birthday Reminder Setting**

Press the (⌚) button to set the Birthday Reminder Alarm. Press the (SET) button, the hour display will begin to flash. Press the (SET) button again to change the minute. Use the (Λ) or (V) button to change current settings. After the changes are complete, press the (SET) button to turn the Birthday Reminder Alarm on or off. When the Birthday Reminder alarm is turned on, a „candle” will be displayed on the LCD screen. On the set date, a birthday song will be played every 3 hours between 9:00 a.m. and 7:00 p.m. On the set time, the alarm will go on once.

**Countdown Timer Setting**

Press the (⌚) button to set the Countdown Timer. Press the (SET) button, the hour display will begin to flash. Press the (SET) button again to change the minute. Use the (Λ) or (V) button to change the current setting between 00:00 to 23:59. After the changes are complete, press the (SET) button to turn Countdown Timer on or off. When the Countdown Timer is turned on, a „⌚” (clock) will be displayed on the LCD screen. When the alarm goes off, the „⌚” will flash.

**Musical Function**

In Normal Mode, press the (V) button to turn the music on or off. When the music is playing, a „🎵” will be displayed on the LCD screen. One of the eight popular musical tunes will be played automatically.

Note: A different starting tune will be played each time the (V) is pressed.

**Snooze Function**

In Normal Mode, press the (Λ) button to turn Snooze on or off. When Snooze is turned on, it will be displayed on the LCD screen. When the Daily Alarm and the Snooze are both turned on, the alarm will sound every three minutes for three times.

Note: When screen display is hazy or musical tones are poor, it may be time to replace the low battery.

This item is in conformity with the following standards:

Electromagnetic Compatibility Directive (EMC) 2014/30/EU  
RoHS Directive 2011/65/EU and its subsequent amendments Directive (EU) 2015/863

Technical information: DC 3.0V (1\*3.0V, SIZE "CR2025")

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. There are adequate means to dispose of this material for proper recycling.

Distributor: Cool Collection, 1476 Budapest, POB. 176. Hungary  
Registration number: 01-09-276783  
Made in China

**AP806904 Loris tolltartó naptárral**  
**Használati útmutató**

**Funkciók:**

- Év/Hónap/nap beállítása 1900. január 01 -2099. december 31 között
- Idő kijelzés
- Hőmérséklet jelzés: -9 C - +59 C fok között
- Ébresztés szundi funkcióval
- Időzítő mód (23 óra 59 perc)
- Születésnap emlékeztető funkció
- Tartalmaz 8 db népszerű ébresztő dallamot
- „Λ”, „V” ezen gombok megnyomásával választhat a funkciók között
- Alacsony 3 V-os elektromos fogyasztás. Energiatakarékos.

**Működési módok:**

Kezelő gombok: MÓD (⌚), ÉBRESZTÉS (🔔), BEÁLLÍTÁS (SET), FEL (Λ), LE (V)

1. (⌚) gomb használatával az alábbi funkciók közül választhat: Idő beállítás – Ébresztés - Születésnap emlékeztetés - Időzítés - Normál mód
2. (🔔) az ébresztő gomb megnyomásával az óra 2 percg sípol és ugyanezen gomb megnyomásával tudja megszüntetni az ébresztést.
3. (SET)
  - (1) SET módban a „SET” gombbal megváltoztathatja az belépéskor megadott adatokat (óra/perc/év/hónap).
  - (2) Normál módban a „SET” gombbal válthat a Celsius/Fahrenheit kijelzési módok között.
  - (3) (⌚) ezen gomb megnyomásával beállíthatja az időzítést majd a „SET” gombbal el tudja indítani.
4. (Λ) gomb
  - (1) SET módban a (Λ) gomb megnyomásával növelni tudja eredeti beállításainak értékét.
  - (2) Normál módban (Λ) ezen gomb megnyomásával a szundi funkció ki és bekapcsolását tudja elvégezni.
5. (V) gomb
  - (1) SET módban a (V) gomb megnyomásával növelni tudja eredeti beállításainak értékét.
  - (2) Normál módban (V) ezen gomb megnyomásával a zene funkció ki és bekapcsolását tudja elvégezni.

**Működési leírás:**

**Idő beállítás:**

Idő beállításához nyomja meg a (⌚) gombot.

Nyomja meg a „SET” gombot, majd használja a „Λ” és „V” gombokat az idő és a dátum beállításához. A sorrend: óra, perc, év, hónap, nap.

**Ébresztés beállítása:**

Ébresztés beállításához nyomja meg a (⌚) gombot. Majd nyomja meg a „SET” gombot az óra kijelző világitásához. Nyomja meg ezt a gombot még egyszer a perc módosításához. Használja a „Λ” és „V” gombokat az ébresztési idő beállításához. Miután beállította a pontos időt akkor a „SET” gomb megnyomásával tudja ki vagy bekapcsolni az ébresztést. Mikor az ébresztés üzemel akkor a kijelzőn az alábbi szimbólum jelenik meg: (🔔)

**Születésnap dátum emlékeztető:**

Születésnap idejére emlékeztető beállításához nyomja meg a (⌚) gombot. Majd nyomja meg a „SET” gombot az óra kijelző világitásához. Nyomja meg ezt a gombot még egyszer a pontos dátum beállításához. Használja a „Λ” és „V” gombokat a dátum és idő beállításához. Miután beállította a pontos időt akkor a „SET” gomb megnyomásával tudja aktivizálni funkciót.

Akár be van kapcsolva az óra akár nem, ha a Születésnap emlékeztető funkció be van állítva akkor az óra LCD kijelzőn egy „gyertya” szimbólum fog világitani. A beállított napon a születésnap dal 3 óránként be fog kapcsolni reggel 09.00 és 19.00 között. A beállított időpontban az emlékeztető egyszer szólal meg.

**Időzítő beállítása:**

Időzítés beállításához nyomja meg a (⌚) gombot. Majd nyomja meg a „SET” gombot az óra kijelző világitásához. Nyomja meg ezt a gombot még egyszer a pontos időzítés beállításához. Használja a „Λ” és „V” gombokat a dátum és idő beállításához 00.00 és 23.59 között. Miután beállította a pontos időt akkor a „SET” gomb megnyomásával tudja be illetve kikapcsolni a funkciót. Ha az időzítés be van kapcsolva akkor a kijelzőn (⌚) ezen szimbólum jelenik meg. Ha az óra kikapcsol az a szimbólum továbbra is világitani fog.

**Zene beállítása:**

Normál módban a „V” gomb megnyomásával tudja indítani a 7 különböző népszerű dallam lejátszását. A LCD kijelző hangjegyekkel jelzi a zenei funkció működését.

Megjegyzés: különböző kezdési dallamok közül választhat ezen „V” gomb megnyomásával.

**Szundi beállítása:**

Normál módban ezen „Λ” gomb megnyomásával tudja a szundi funkciót beállítani. A szundi funkciót az LCD kijelzője jelzi. Amikor az óra és a szundi funkció is be van kapcsolva az ébresztő minden 3. percben 3szor jelez.

Megjegyzés: Amikor az óra kijelzője homályosan világít vagy a zene nem szól erőteljesen akkor érdemes kicserélni az elemet.

Ez a termék az alábbi irányelveknek felel meg:

Elektromágneses összeférhetőség (EMC) – 2014/30/EU irányelv  
RoHS 2.0 2011/65/EU irányelv és későbbi módosításai (EU) 2015/863

Technikai adatok: DC 3.0V (1\*3.0V, SIZE "CR2025")

VIGYÁZAT: Nem megfelelő elem használata esetén robbanásveszély áll fenn. Az elhasznált elemeket az utasításoknak megfelelően ártalmatlanítsa.



Ez a szimbólum a termék csomagolásán és a használati útmutatón jelzi, hogy a készülék élettartama lejártá után a szelektív gyűjtőbe kerüljön elkülönítve a háztartási hulladéktól. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információkért keresse a helyi hatóságot.

Forgalmazó: Cool Collection, 1476 Budapest, Pf.:176. Magyarország  
Cégjegyzékszám: 01-09-276783  
Származási ország: Kína