

AP810462
Multifunkcionális LCD óra / időjárás állomás
Használati utasítás

Funkciók:

Hőmérséklet skála: 0°C-50°C (32°F-122°F)
Páratartalom: 20% - 99% között
Pontosság: 1°C
Kijelzi a maximum és minimum hőmérsékletet, páratartalmat
Naptár – 2001-2099
2 db AAA elemmel működik (nem tartozék)

Működés:

A naptár megnyitásához nyomja meg a MODE gombot.
Az ébresztő megnyitásához nyomja meg a MODE gombot

Idő beállítás:

Az idő beállításához tartsa nyomva a gombot 3 másodpercig.
Állítsa be az óra számjegyeit a FEL (UP) és LE (DOWN) gombok segítségével.
Nyomja meg a MODE gombot újra.
Használja a FEL (UP) és LE (DOWN) gombokat a perc beállításához.

Ébresztő beállítás:

Az ébresztő megnyitásához nyomja meg a MODE gombot.
Az ébresztő beállításához tartsa nyomva a MODE gombot.
Használja a FEL (UP) és LE (DOWN) gombokat az óra számjegyeinek beállításához.
Nyomja meg a MODE gombot újra.
Használja a FEL (UP) és LE (DOWN) gombokat a perc számjegyeinek beállításához.

Naptár beállítás:

A naptár megnyitásához nyomja meg a MODE gombot.
A naptár beállításához tartsa nyomva a MODE gombot. Használja a FEL (UP) és LE (DOWN) gombokat az év számjegyeinek beállításához.
Nyomja meg a MODE gombot újra.
Használja a FEL (UP) és LE (DOWN) gombokat a hónap beállításához.
Nyomja meg a MODE gombot újra.
Használja a FEL (UP) és LE (DOWN) gombokat a nap beállításához.

Az ébresztő be- és kikapcsolása:

Az ébresztő bekapcsolásához nyomja meg a FEL (UP) gombot.

MAX/MIN gomb:

A rögzített maximum hőmérséklet és páratartalom megtekintéséhez nyomja meg a MAX/MIN gombot.
A rögzített minimum hőmérséklet és páratartalom megtekintéséhez nyomja meg a MAX/MIN gombot újra.

12/24 órás formátum

Az időforma megváltoztatásához nyomja meg a FEL (UP) gombot 3 másodpercig.

Hőmérséklet mértékegysége:

A hőmérséklet mértékegységének (°C /°F) megváltoztatásához tartsa nyomva a LE (DOWN) gombot.

Az ébresztő szundi módja:

Az ébresztő szundi módjához nyomja meg a SNZ gombot ébresztéskor.

Ez a termék az alábbi irányelveknek felel meg:

RoHS 2.0 2011/65/EU irányelv és későbbi módosításai (EU) 2015/863
Elektromágneses összeférhetőségre vonatkozó irányelv (EMC) – 2014/30/EU

VIGYÁZAT: Nem megfelelő elem használata esetén robbanásveszély áll fenn. Az elhasznált elemeket az utasításoknak megfelelően ártalmatlanítsa.



Ez a szimbólum a termék csomagolásán és a használati útmutatóján jelzi, hogy a készülék élettartama lejárt után a szelektív gyűjtőbe kerüljön elkülönítve a háztartási hulladéktól. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információért keresse a helyi hatóságot.



Forgalmazó: Cool Collection, 1476 Budapest, Pf.:176. Magyarország
Cégjegyzékszám: 01-09-276783
Származási ország: Kína

AP810462
Multifunctional LCD clock / weather station
User manual

Functions:

Temperature scale: 0°C-50°C (32°F-122°F)
Moisture scale: between 20% - 99%
Accuracy: 1°C
Displays maximum and minimum temperature, humidity
Readings calendar from 2001 to 2099
Operates with 2 AAA batteries (not included)

Management:

To view the calendar, press the MODE button.
To check the alarm time, press the MODE button

Setting the time:

To switch to time setting mode, press and hold the button for 3 seconds.
The flashing hour digits are set with the UP and DOWN buttons.
Press the MODE button again.
Use the UP and DOWN buttons to set the flashing minute digits.

Setting the alarm:

To check the alarm time, press the MODE button.
To switch to alarm setting mode, press and hold the MODE button.
Use the UP and DOWN buttons to set the flashing hour digits.
Press the MODE button again.
Use the UP and DOWN buttons to set the flashing minute digits.

Setting the calendar:

To view the calendar, press the MODE button.
To switch to calendar setting mode, hold down the MODE button. Use the UP and DOWN buttons to set the flashing year digits.
Press the MODE button again.
Use the UP and DOWN buttons to set the flashing month digits.
Press the MODE button again.
Use the UP and DOWN buttons to set the flashing day digits.

Turning the alarm on and off:

To turn the alarm on, press the UP button.

MAX/MIN button:

To view the maximum recorded temperature and humidity, press MAX / MIN.
To view the minimum recorded temperature and humidity, press the MAX / MIN button again.

12/24 format selection:

To change the time format, press the UP button for 3 seconds.

Temperature scale format:

To change the temperature scale °C /°F, press the DOWN button.

Snooze the alarm:

To snooze the alarm, press the SNZ button during a call.

This item is in conformity with the following standards:
RoHS Directive 2011/65/EU and its amendment directives (EU) 2015/863
Electromagnetic Compatibility Directive (EMC) 2014/30/EU

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. There are adequate means to dispose of this material for proper recycling.



Distributor: Cool Collection, 1476 Budapest, POB. 176. Hungary
Registration number: 01-09-276783
Made in China