



AP723148 Earphones Shizar RCS / Shizar RCS bluetooth fülhallgató

FRONT PART


AP723148
Shizar RCS Bluetooth Fülhallgató
Használati Útmutató



Javasoljuk, hogy figyelmesen olvassa el ezt a használati utasítást és tartsa meg a jövőbeli felhasználáshoz.



Termék leírása:



Töltőállomás
Multifunkcionális gomb

Technikai adatok:

- Bluetooth 5.1v.
- Hatótávolság: Legfeljebb 10 méter
- Frekvencia: 20Hz-20KHz
- Fülhallgatók: Litium polimer akkumulátor 30mAh
- Töltőállomás: Litium polimer akkumulátor 300mAh
- Töltési feszültség: 5V
- Töltési idő: 1-1.5ó
- Működési idő: 4-5ó
- SNR: 92dB
- Impedancia: 32ohms
- Torzítás: kevesebb, mint 6%
- Kompatibilis A2DP, AVCTP, AVDTP, AVRCP, HFP, SPP
- Töltő kábelt tartalmazza.

Töltés:

Töltő állomás

Használja a hozzá tartozó kábelt a töltéshez. Csatlakoztassa az USB kábelt számítógéphez / AC adapterhez és csatlakoztassa a kábel másik oldalát a töltőállomás töltő portjához. A töltési folyamat során, a led jelzőfény fehéren fog villogni. Ha végzett, a led fény folyamatosan fog világítani.

Megjegyzés: Ha a fülhallgatók a töltőállomásban vannak, mindkettő egyszerre fog tölteni.

Fülhallgatók

Helyezze a fülhallgatókat a töltőállomásba és a töltési folyamat automatikusan elkezdődik.

A töltés során a fehér fény égve marad. Amikor a fülhallgatók teljesen feltöltődnek a jelzőfény kialszik.

Használat:

Használhatja csak az egyik vagy mindkét fülhallgatót egyszerre.

Amikor kiveszi a fülhallgatókat a töltőállomásból automatikusan szinkronizálódnak.

Ha kikapcsolt állapotban vannak, tartsa nyomva a multifunkcionális gombot a bekapcsoláshoz, amíg a jelzőfény fehéren kezd villogni. Ez jelzi, hogy az eszköz párosításra készen áll.

A készüléke Bluetooth menüjét használva keressen új készülékeket, majd válassza ki a "1983"-at a csatlakozáshoz. Miután a kapcsolat sikeresen létrejött, az egyik fülhallgató jelzőfénye kialszik majd.

Tartsa nyomva a multifunkcionális gombot a mindkét fülhallgatón az eszköz kikapcsolásához.

Irányítás:

Hívás fogadása/befejezése:
Röviden nyomja meg valamelyik fülhallgató multifunkcionális gombját.

Hívás elutasítása:
Hosszan nyomja le valamelyik fülhallgató multifunkcionális gombját.

Zene lejátászása/megállítása:
Rövid nyomja meg valamelyik fülhallgató multifunkcionális gombját.

Következő/előző zeneszám:
A következő számra való lépéshez nyomja meg kétszer a multifunkcionális gombot a jobb fülhallgatón. Az előző szám lejátszásához alkalmazza ugyan ezeket a lépéseket csak a bal fülhallgatón.

Hangerő:
A hangerő növeléséhez nyomja meg háromszor a multifunkcionális gombot a bal fülhallgatón. A hangerő csökkentéséhez ugyanígy járjon el, csak a bal fülhallgatón.


Hibaelhárítás:

Probléma	Megoldás
Nem tud csatlakozni más eszközökhöz.	1. Ellenőrizze, hogy a fülhallgató még mindig keresés folyamatban van vagy kapcsolja ki és újra be. 2. Túl sok Bluetooth eszköz van a közelben, ami nehézséget okoz a kapcsolat létrehozásában. Kapcsolja ki a többi Bluetooth eszközt. 3. Biztosítsa, hogy a fülhallgató "Pairing Mode"-ban van.
A hang halk vagy torz.	4. Ellenőrizze a Bluetooth eszköz hangját és utána állítsa a megfelelő szintre. 5. Töltse fel az akkumulátort.
Alkalmanként megáll a zene.	6. Ellenőrizze, hogy a hangszóró megfelelő hatótávon belül van-e vagy hogy van-e valamilyen akadály hangszóró és a többi Bluetooth eszköz között.



Figyelmeztetések:

1. Ne tegye ki ezt a terméket esőnek vagy nyirkos, párás körülményeknek.
2. Előzze meg az eszköz leesését, mivel az komoly károkat okozhat.
3. Ne szerelje szét, javítsa meg vagy módosítsa a terméket egyedül. Meghibásodás esetén lépjen kapcsolatba egy jogosult szakemberrel.
4. A kockázatok elkerülése érdekében csak erre kijelölt helyen dobja ki az eszközt, és ne dobja tűzbe, mivel beépített Litium akkumulátorral rendelkezik.
5. Az eszközt száraz ruhával tisztítsa.
6. Ne helyezze az eszközt hőforrások közelébe, ne tegye ki direkt napfénynek.
7. Ne helyezzen fém tárgyat az eszközbe, mivel rövidzárlatot vagy áramütést okozhat.
8. A fülhallgató és fejhallgató magas hangerőn való használata maradandó halláskárosodáshoz vezethet.
9. Tartsa távol gyerekektől.

Ez a termék az alábbi irányelveknek felel meg: RoHS 2.0 2015/85/EU irányelv és későbbi módosítással (EU) 2015/863 Rádióberendezésekről szóló irányelv (RED) - 2014/53/EU




Ez a szimbólum azt jelenti, hogy az eszköz elektromos élettartamának lejártá után az Ön háztartási hulladékaól elkülönítetten kell újrahasznosítani. Ennek megfelelően dobja a kijelölt hulladékgyűjtőbe. További információért hívja a helyi hatóságokat.


Forgalmazó: Cool Collection, 1476 Budapest, Pf: 176, Magyarország
Céggjegyzékszám: 01-09-276783
Szármaazási ország: Kína

BACK PART


AP723148
Earphones Shizar RCS
User manual



It is recommended to read this user manual carefully and keep it for future reference.



Product overview:



Charging port
Multifunction button

Specifications:

- Bluetooth Version 5.1
- Operating distance: Up to 10 meters
- Frequency: 20Hz-20KHz
- Earphones: Lithium polymer battery 30mAh
- Charging station: Lithium polymer battery 300mAh
- Charging voltage: 5V
- Charging time: 1-1.5h
- Working Time: 4-5h
- SNR: 92dB
- Impedance: 32ohms
- Distortion: less than 6%
- Compatible with A2DP, AVCTP, AVDTP, AVRCP, HFP, SPP
- Charging cable included

Charging:

Charging station

Use the cable provided for charging. Connect USB cable to computer / AC adapter and connect the other end of the cable into the charging port of the charging station. During the charging process, the led indicator will blink in white colour. Once finished, led indicator will stay on.

Note: If the earphones are in the charging station, both will be charged at the same time.

Earphones

Place the earphones into the charging station and the charging process will start automatically.

During charging the white light will stay on. When the earphones are fully charged the indicator light will turn off.

Operation:

You can use one or both earphones at the same time. When you remove the earbuds from the charging station they will synchronize automatically.

If they are turned off, press and hold the multifunction button to power on the earphone until the indicator light start flashing in white colour. This indicates that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "1983" to pair. Once they are paired successfully, the light indicator will turn off in one of the earphones.

Press and hold the multifunction button of each earphone to power off the device.

Controls:

Answer/End call:
Short press the multifunction button of any earphone.

Reject call:
Long press the multifunction button of any earphone.

Play/Pause music:
Short press the multifunction button of any earphone.

Next/previous Track:
To go to next track, press two times the multifunction button on the right earphone. To go to previous track, proceed in same way on the left earphone

Volume:
To increase the volume level, press three times the multifunction button on the right earphone. To decrease the volume level, proceed in same way on the left earphone


Troubleshooting

Fault	Solution
Unable to pair up with other devices.	1. Check whether the earphone is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphone is in "Pairing Mode".
The sound is low or distorted.	4. Check the Bluetooth device's volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the earphone effective transmission range is exceeded or if there is an obstacle standing between the earphone and other Bluetooth devices.



Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Excessive sound pressure from earphones and headphones can cause hearing loss.
9. Keep out of reach of children.

This item is in conformity with the following standards: RoHS Directive 2011/65/EU and its subsequent amendments Directive (EU) 2015/863 Radio Equipment Directive (RED) - Directive 2014/53/EU



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Distributor: Cool Collection, 1476 Budapest, Pf: 176, Hungary
Registration nr.: 01-09-276783
Made in China