

AP723153 Speaker Durbal / Durbal Bluetooth Hangszóró

FRONT PART

AP723153 Durbal bluetooth hangszóró Használati Útmutató




Javasoljuk, hogy figyelmesen olvassa el ezt a használati utasítást és tartsa meg a jövőbeli felhasználáshoz.

Termék leírás:

1. Hangszóró
2. Multifunkcionális gomb
3. Töltési port
4. Lámpa
5. Jelzőfény

Technikai adatok:

- Bluetooth 5.0v.
- Töltési feszültség: 5V
- Litium polimer akkumulátor 300mAh, 3.7V
- Működési idő: Legfeljebb 3 óra
- Hatótávolság: Legfeljebb 10 méter
- Frekvencia: 90Hz-20KHz
- Impedancia: 4Ohms
- Potencia: 3W
- THD: <1%
- SNR: >90dB



Használat:

Nyomja meg hosszan a multifunkcionális gombot a hangszóró bekapcsolásához. A kék jelzőfény villogással jelzi, hogy a készülék kész a párosításra.

A mobil eszköze Bluetooth menüjében keresse meg és csatlakozzon a "1989" nevű eszközökhöz. Sikeres csatlakozás után hallani fog egy értesítő hangot és a jelzőfény villogítani fog.

Nyomja meg röviden a multifunkcionális gombot a lámpa be/ki kapcsolásához.

Tartsa nyomva hosszan a multifunkcionális gombot a hangszóró kikapcsolásához.

Töltés:

Használja a töltésre biztosított kábelt. Csatlakoztassa az USB kábelt számítógéphez/AC adapterhez. Csatlakoztassa a kábel C típusú végét a készüléke USB C portjába.

A töltés ideje alatt a jelzőfény pirosan fog villogítani. Amikor a hangszóró teljesen feltöltött a fény kialszik.

Hibaelhárítás:

Probléma	Megoldás
Nem tud csatlakozni más eszközökhöz.	<ol style="list-style-type: none"> 1. Ellenőrizze, hogy a fülhallgató még mindig keresés folyamatában van vagy kapcsolja ki és újra be. 2. Túl sok Bluetooth eszköz van a közelben, ami nehézséget okoz a kapcsolat létrehozásában. Kapcsolja ki a többi Bluetooth eszközöket. 3. Biztosítsa, hogy a fülhallgató "Pairing Mode"-ban van.
A hang halk vagy torz.	<ol style="list-style-type: none"> 4. Ellenőrizze a Bluetooth eszköz hangját és utána állítsa a megfelelő szintre. 5. Töltse fel az akkumulátort.
Alkalmanként megáll a zene.	<ol style="list-style-type: none"> 6. Ellenőrizze, hogy a hangszóró megfelelő hatótávra van-e állítva és hogy van-e valamilyen akadály a hangszóró és a többi Bluetooth eszköz között.

Figyelmeztetések:

1. Ne tegye ki ezt a terméket esőnek vagy nyirkos, páras körülményeknek.
2. Előzze meg az eszköz leesését, mivel az komoly károkat okozhat. Ne szerelje szét, javítsa meg vagy módosítsa a terméket egyedül.
3. Meghibásodás esetén lépjen kapcsolatba egy jogosult szakemberrel.
4. A kockázatok elkerülése érdekében csak erre kijelölt helyen dobja ki az eszközt, mivel beépített Litium akkumulátorral rendelkezik.
5. Az eszközt száraz ruhával tisztítsa.
6. Ne helyezze az eszközt hőforrások közelébe, ne tegye ki direkt napfénynek.
7. Ne helyezzen fém tárgyat az eszközbe, mivel rövidzárlatot vagy áramütést okozhat.
8. Tartsa távol gyermekektől..

Ez a termék az alábbi irányelveknek felel meg:
RoHS 2.0 2011/65/EU irányelv és későbbi módosításai (EU) 2015/863
Rádióberendezésekről szóló irányelv (RED) – 2014/53/EU



Ez a szimbólum azt jelenti, hogy az eszköz elektromos élettartamának lejártá után az Ön háztartási hulladékaól elkülönítetten kell újrahasznosítani. Ennek megfelelően dobja a kijelölt hulladékgyűjtőbe. További információkért hívja a helyi hatóságokat.



Forgalmazó: Cool Collection,
1476 Budapest, Pf: 176, Magyarország
Cégjegyzékszám: 01-09-276783
Számzási ország: Kina

BACK PART

AP723153 Speaker Durbal User Manual




It is recommended to read this user manual carefully and keep it for future reference.

Product Overview:

1. Speaker
2. Multifunction button
3. Charging port
4. Light
5. Light indicator

Specifications:

- Bluetooth version 5.0
- Charging voltage: 5V
- Lithium battery 300mAh 3.7V
- Working Time: up to 4h
- Operating distance: up to 10 meters
- Frequency: 90Hz-20KHz
- Impedance: 4Ohms
- Power output: 3W
- THD: <1%
- SNR: >90dB



Operation:

Long press the multifunction button to power on the speaker. The blue indicator light will start flashing to indicate that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "1989" to pair. Once they are successfully paired, you will hear a confirmation sound and the indicator light will stay fixed.

Short press the multifunction button to turn on/off the light.

Long press the multifunction button to power off the speaker.

Charging:

Connect the charger to an appropriate power source using the supplied cable.

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

Troubleshooting:

Fault	Solution
Unable to pair with other devices.	<ol style="list-style-type: none"> 1. Check whether the speaker is still in the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your device is in "Pairing Mode".
The sound is low or distorted.	<ol style="list-style-type: none"> 4. Check the Bluetooth device volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	<ol style="list-style-type: none"> 6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children.



This item is in conformity with the following standards:
RoHS Directive 2011/65/EU and its subsequent amendments Directive (EU) 2015/863 Radio Equipment Directive (RED) - Directive 2014/53/EU



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.



Distributor: Cool Collection,
1476 Budapest, Pf: 176, Hungary
Registration nr.: 01-09-276783
Made in China