

# 180x260mm

## USER MANUAL

### Specification:

Item no.: AP810460  
Capacity: 4000 mAh / 3.7V (Li-polymer battery)  
Rated capacity: 14.8Wh  
Product weight: 122 g  
Product size: 68 x 10 x 110 mm  
Input: DC5V 1000 mA  
Output: DC5V 1000 mA  
Max Charge Current: 1000 mA  
Charging time: 4-5 hours  
Cycle life: ≥ 500 times

### Instructions:


#### Charging the Power bank:

The Power bank can be plugged into the computer with a standard USB cable or connected to a USB adaptor. Another side is to be connected to the DC 5V IN port, which will automatically start charging when connected. The blue battery indicator will be flashing when charging, and stop flashing when fully charged.

#### Charging your smartphone or other digital devices:

Please connect the Power bank and the smartphone with a standard USB cable. If you press the Switch, it will start charging and the blue battery indicator will be on. The indicator will turn off automatically when fully charged. There are 4 grid battery indicators, each case 25%.

If you press Switch, the battery indicator light will show how much energy remains. The indicator light will turn off automatically after 32 seconds. LED backlight indicator is synchronous as power bank's working indicator.



### Note:

Please check if the USB port and cable are connected properly when charging. If the connection is not stable, the device may not charge because of a built-in IC (Short Circuit Protection) system. When the connection is stabilized, it will resume charging. Please make sure to charge the battery at least once every three months. It is normal for the device to feel slightly warm when charging.


### Features:

This product is a high capacity portable charger, with a fashionable design. It can be very convenient for people with multiple accessories in need of charging. It is compatible with most mobile phones and digital devices, with an internal battery that has great storage capacity. Durability is excellent, as it can charge batteries over 500 times. This power bank is suited for daily use, and can help you out if you are suddenly out of battery power.

### Safety Instructions, care and maintenance:

The power bank unit contains an internal 4000mAh Li-polymer battery. Upon initial use or after a prolonged period of storage, fully charge the unit before use. The unit will reach its maximum performance after 2 or 3 full charging and discharging cycles. Using an incorrect power adaptor or USB cable could cause damage to both your mobile devices and the power bank. Do not submerge in water or expose to adverse weather conditions. Avoid dropping the device. Keep the unit away from extreme high and low temperatures, out of direct sunlight, and away from water, humidity and any liquids. Do not use abrasive solvents or expose to sharp objects. Keep out of reach of children. Do not dispose of in a fire for risk of explosion. Do not attempt to disassemble device. Repairs to electrical equipment should only be performed by a qualified electrician. Do not use if the unit is moist in order to avoid danger of electric shock, explosion or injury to self. Do not use if the unit has been damaged.

### THIS IS NOT A TOY

 This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.



AP810460 Power bank  
Distributor: Cool Collection, 1476 Budapest, POB. 176. Hungary  
Registration number: 01-09-276783  
Made in China

front

## HASZNÁLATI UTASÍTÁS

### Specifikációk:

Cikkszám: AP810460  
Kapacitás: 4000 mAh / 3.7V (Lítium-polimer akkumulátor)  
Névleges kapacitás: 14.8Wh  
Termék tömege: 122 g  
Termék mérete: 68 x 10 x 110 mm  
Bemenet: DC5V 1000 mA  
Kimenet: DC5V 1000 mA  
Maximális töltési áram: 1000 mA  
Töltési idő: 4-5 óra  
Ciklus élettartam: ≥ 500 alkalom

### Használati utasítás:


#### A power bank töltése:

A Power Bankot számítógéphez vagy USB adapterhez szabvány USB kábellel tudja csatlakoztatni. A másik oldalát csatlakoztassa a DC 5V IN csatlakozóhoz, ami ilyenkor automatikusan elkezd tölteni. A kék jelző fény elkezd villogni töltéskor, a villogás megszűnik, amikor teljesen feltöltődött.

#### Okostelefon és más digitális eszközök töltése:

Szabvány USB kábellel csatlakoztassa az okos telefont a power bankhoz. Ha megnyomja a kapcsolót, elkezd tölteni és a kék töltöttséget jelző fény világít. A kék jelzőfény automatikusan kikapcsol, amikor teljesen feltöltött. Összesen 4 kék jelzőfény van, mindegyik egység 25% töltöttséget jelöl.

Ha megnyomja a gombot, a jelzőfény megmutatja mennyi töltés maradt még. A jelzőfény automatikusan kikapcsol 32 másodperc után. A LED háttérvilágítás a power bank jelzőfényével szinkronban működik.



### Megjegyzés:

Kérjük ellenőrizze, hogy az USB csatlakozó és a kábel helyesen csatlakozzon töltéskor. Ha a csatlakozás nem stabil, akkor nem fog tölteni a beépített IC (Rövidzárlat Védelem) rendszer miatt. Amikor stabilizálódik, akkor folytatódik a töltés. Ügyeljen arra, hogy minden 3. hónapban legalább egyszer töltsen az akkumulátort. Az eszköz felmelegedése normális töltéskor.


### Jellemzők:

A termék egy nagy kapacitású hordozható töltő, divatos kialakítással. Hasznos termék lehet főleg azoknak, akiknek egyszerre több elektronikai eszköz töltésére van szükségük. Kompatibilis a legtöbb telefontal és digitális eszközzel, belső akkumulátorral, mivel nagy a tároló kapacitása. Tartóssága kiváló, több mint 500 alkalommal képes töltésre. A power bank alkalmas mindennapi használatra, amikor hirtelen lemerül a készülékünk.

### Biztonsági utasítások, gondoskodás és fenntartás:

A belső tápegység 4000mAh Lítium-polimer akkumulátort tartalmaz. Az első használatkor és hosszabb tárolási idő után töltsen fel teljesen az egységet. A készülék maximális teljesítményét 2 vagy 3 teljes töltési és kisütési ciklus után éri el. Helytelen tápegység vagy USB-kábel használata kárt okozhat a mobil eszközben és a power bankban is. Ne merítse vízbe és ne tegye ki kedvezőtlen időjárási körülményeknek. Ne ejtse le a készüléket. Tartsa távol a készüléket túl magas, illetve túl alacsony hőmérséklettől, közvetlen napfénytől, valamint víztől, nedvességtől vagy bármilyen folyadéktól. Ne használjon súroló szereket és ne érintkezzen éles eszközökkel. Gyerekektől tartsa távol. Ne dobja el a terméket tűz és robbanás veszélyes környezetben. Ne próbálja meg szétszedni a terméket. Az elektronikai részeket, csak hozzáértő, képzett ember javíthatja. Ne használja a készüléket, ha nedves, hogy elkerülje az elektromos áramütést, robbanást vagy sérülést. Ne használja, ha a termék sérült.

### NEM JÁTÉKSZER

 Ez a szimbólum a termék csomagolásán és a használati útmutatón jelzi, hogy a készülék élettartama lejártá után a szelektív gyűjtőbe kerüljön elkülönítve a háztartási hulladéktól. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információkért keresse a helyi hatóságot.



AP810460 Power bank  
Forgalmazó: Cool Collection, 1476 Budapest, Pf.:176. Magyarország  
Cégjegyzékszám: 01-09-276783  
Szarmazási ország: Kína

back