

AP721504 Wanap Speaker/Wanap bluetooth hangszóró


**AP721504
Wanap Bluetooth Speaker
User manual**



It is recommended to read this user manual carefully and keep it for future reference.

Product Overview:

1. Main control button
2. Micro USB Input
3. Aux Controls
4. Microphone



Specifications:

- Bluetooth version 5.0
- Charging voltage: 5V
- Lithium battery 200mAh 3.7V
- Working Time: up to 3h
- Operating distance: up to 10 meters
- Frequency: 100Hz-20KHz
- Impedance: 4ohms
- Power output: 3W
- THD: less than 5%
- SNR: 65dB

Operation:

Keep pushed the main control button to power on the speaker. The indicator light will start flashing to indicate that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "6506" to pair. Once they are paired successfully, you will hear a notification sound and the light will stay on.




Keep pushed the main control button to power off the speaker.

Charging:

Use the cable provided for charging. Connect the USB cable to computer / AC adapter. Connect the Micro USB end of this cable into the Micro USB port of your device.

While charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

Controls:

	<ul style="list-style-type: none"> • Short-press the button to next song • Long-press the button to increase the volume. (When maximum volume is reached, you will hear a notification sound)
	<ul style="list-style-type: none"> • Short-press the button to previous song. • Long-press the button to decrease the volume. (When minimum volume is reached, you will hear a notification sound)
	<ul style="list-style-type: none"> • Short-press the button to answer/end a call. • Short-press the button to play/pause the music. • Long press the button to reject an incoming call. • Double press the button to reject the last outgoing phone number


Troubleshooting:

Fault	Solution
Unable to pair with other devices.	<ol style="list-style-type: none"> 1. Check whether the speaker is still in the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your device is in "Pairing Mode".
The sound is low or distorted.	<ol style="list-style-type: none"> 4. Check the Bluetooth device volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	<ol style="list-style-type: none"> 6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

 This symbol both in the product and its user manual indicates that at the end of the device's electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

CE RoHS

Distributor: Cool Collection, 1476, Budapest, POB:176, Hungary Registration nr.:01-09-276783, Made in China

**AP721504
Wanap bluetooth hangszóró
Használati útmutató**



Javasoljuk, hogy alaposan olvassa el a használati útmutatót és őrizze meg későbbi felhasználás céljából!

Termék áttekintés:

- 1.Fő vezérlő gomb
- 2.Micro USB bemenet
- 3.AUX vezérlés
- 4.Mikrofon

Technikai adatok:

- Bluetooth verzió 5.0
- Töltési feszültség: 5V
- Lithium akkumulátor 200mAh 3.7V
- Működési idő: 3h
- Működési távolság: 10 méterig
- Frekvencia: 100Hz -20KHz
- Ellenállás:40hm
- Teljesítmény:3W
- THD:>5%
- SNR: 65dB



Működés:

Nyomja hosszan a fővezérlő gombot a hangszóró bekapcsolásához. Jelzfény villogni kezd ami jelzi, hogy az eszköz kapcsolódásra kész állapotban van.




Eszközének Bluetooth menüjéből keresse meg és válassza ki a „6506” lehetőséget és csatlakoztassa. Sikeres csatlakoztatás esetén egy értesítési hangot fog hallani és a jelzfény világitani fog.

Tartsa nyomva a fővezérlő gombot a hangszóró kikapcsolásához.

Töltés:

Töltés esetén használja a termékhez mellékelt kábelt. Csatlakoztassa az USB kábelt számítógéphez vagy az AC adapterhez. Csatlakoztassa a Micro USB kábel végét a készülék Micro USB portjához. Töltés közben a jelzfény pirosan világit. Amikor a hangszóró teljesen feltöltött a jelzfény kialszik.

Controls:

	<ul style="list-style-type: none"> - nyomja meg röviden a gombot a következő zenéhez. - nyomja meg hosszan a gombot a hangerő növeléséhez (mikor eléri a maximum hangerőt jelző hangot fog hallani)
	<ul style="list-style-type: none"> -nyomja meg röviden a gombot az előző zeneszámhoz. -nyomja meg hosszan a gombot a hangerő csökkentéséhez. (mikor eléri a minimum hangerőt jelző hangot fog hallani)
	<ul style="list-style-type: none"> -nyomja meg röviden a gombot hívás kezdéshez vagy befejezéshez -nyomja meg röviden a gombot a zene leállításához/ befejezéshez. -nyomja meg hosszan a gombot bejövő hívás elutasításához. -duplán nyomva a gombot az utolsó hívott számot tudja vissza hívni.


Hibaelhárítás

Hiba	Megoldás
Nem tud kapcsolódni más eszközökhöz.	<ol style="list-style-type: none"> 1. Ellenőrizze, hogy a fülhallgató még mindig keresi-e a készüléket, vagy kapcsolja ki és újra be az. 2. Problémát okozhat a csatlakozásban, ha több Bluetooth eszközt találhat a közelében. Kapcsolja ki a többi Bluetooth eszközt. 3. Bizonyosodjon meg arról, hogy az eszköz párosítási módban van.
A hang halk vagy torz.	<ol style="list-style-type: none"> 4. Ellenőrizze a Bluetooth eszközön a hangerőt, majd állítsa be a kívánt szintre. 5. Töltse fel az akkumulátort.
Időnként a zene megáll.	<ol style="list-style-type: none"> 6. Ellenőrizze, hogy túllépte-e a fülhallgató tényleges érvényes tartományát, illetve, hogy van-e akadály a fülhallgató és más Bluetooth-eszközök között.

Figyelmeztetés:

- 1.Ne tegye ki a terméket esőnek vagy párák körülményeknek.
- 2.Akadályozza meg a termék leesését, mert az komoly kárt okozhat.
- 3.Ne szedje szét, javítsa-vagy módosítsa az eszközt önmagától, kessen fel egy szakemberrel.
- 4.A kockázatok elkerülése végett ne szabaduljon meg a terméktől helytelenül, mert beépített Lithium akkumulátort tartalmaz.
- 5.Tisztítsa a hangszórót száraz törlőruhával.
- 6.Ne helyezze az eszközt hőforrás közelébe, - illetve ne tegye ki direkt napfénynek.
- 7.Ne helyezzen semmilyen fém tárgyat az eszközbe, mert az rövidzárlatot okozhat.
- 8.Gyermekektől távol tartandó.

VIGYÁZAT: Nem megfelelő elem használata esetén robbanásveszély áll fenn. Az elhasznált elemeket az utasításoknak megfelelően ártalmatlanítsa.

 Ez a szimbólum a termék csomagolásán és a használati útmutatóján jelzi, hogy a készülék élettartama lejártá után a szelektív gyűjtőbe kerülőn elkülönítve a háztartási hulladéktól. Ez a jel gondoskodik az alapsanyag megfelelő újra hasznosításáról. További információkért keresse a helyi hatóságát.

CE RoHS

Forgalmazó: Cool Collection, 1476, Budapest, Pf.176, Magyarország Cégjegyzékszám: 01-09-276783, Származási ország: Kína