

AP723199 Headphones Helton / Helton fülhallgató

FRONT PART

AP723199 Helton fülhallgató Használati útmutató



Javasoljuk, hogy figyelmesen olvassa el ezt a használati utasítást és tartsa meg a jövőbeli felhasználáshoz.

Termék leírás:



Technikai adatok:

- Bluetooth 5.3
- Hatótávolság: Legfeljebb 10 méter
- Frekvencia: 20Hz-20KHz
- Impedancia: 50 Ohms
- SNR: >85dB
- Torzítás: kevesebb, mint 5%
- Lítium polimer akkumulátor 250mAh
- Töltési feszültség: 5V
- Működési idő: 5-6h
- Töltési idő: 1-2h
- Kompatibilis HFP/AVRCP/A2DP
- Töltő kábelt tartalmazza

Töltés:

Csatlakoztassa az eszközt egy energiaellátó egységhez a tartozék kábelrel.

A töltés alatt a jelzőfény pirosan fog villogni. Amikor a töltő állomás teljesen feltöltődött a fény kékre fog váltani.

Használat:

Nyomja meg és tartsa lenyomva a multifunkcionális gombot a fejhallgató bekapcsolásához, amíg a jelzőfény pirosan és kéken kezd el villogni. Ez jelzi, hogy az eszköz készen áll a párosításra.

A mobil eszköze Bluetooth menüjében keresse meg és csatlakozzon a "1960" nevű eszközhöz. Amikor megfelelően párosítva vannak a fény lassan kezd villogni.

Tartsa lenyomva az egyik fülhallgató multifunkcionális gombját körülbelül 5 másodpercig a kikapcsoláshoz.

SD kártyáról való zenelejátszás

Miután a fejhallgatót bekapcsolta, helyezzen a micro SD kártyát a nyílásba és a fejhallgató automatikusan elkezd lejátszani a zenét.

Irányítás:

Hívás fogadása/befejezése:

Röviden nyomja meg a multifunkcionális gombot.

Hívás elutasítása:

Hosszan nyomja le a multifunkcionális gombot.

Mód változtatása (Bluetooth/SD kártya):

Nyomja meg kétszer a multifunkcionális gombot a mód változtatásához.

Zene lejátszása/megállítása:

Röviden nyomja meg a multifunkcionális gombot.

Következő/előző zeneszám:

A következő számra lépéshez tartsa nyomva a + gombot. Az előző számra váltáshoz alkalmazza az előző módszert a - gombbal.

Hangerő növelése/csökkentése:

A hangerő növeléséhez nyomja meg a + gombot (Hallani fog egy jelző hangot, ha elérte a maximum szintet). A hangerő csökkentéséhez nyomja meg a - gombot.

Hang asszisztens:

Nyomja meg a multifunkcionális gombot egy pillanatra, hogy elindítsa az okos telefonjára hangolt hang asszisztent.

Hibaelhárítás

Probléma	Megoldás
Nem tud csatlakozni más eszközökhöz.	1. Ellenőrizze, hogy a fülhallgató még mindig keresés folyamatában van vagy kapcsolja ki és újra be. 2. Túl sok Bluetooth eszköz van a közelben, ami nehézséget okoz a kapcsolat létrehozásában. Kapcsolja ki a többi Bluetooth eszközt.
A hang halk vagy torz.	4. Ellenőrizze a Bluetooth eszköz hangját és utána állítsa a megfelelő szintre. 5. Töltsé fel az akkumulátort.
Alkalmanként megáll a zene.	6. Ellenőrizze, hogy a hangszóró megfelelő hatótávon belül van-e vagy hogy van-e valamilyen akadály hangszóró és a többi Bluetooth eszköz között.

Figyelmeztetések:

1. Ne tegye ki ezt a terméket esőnek vagy nyirkos, párák körülményeknek.
2. Előzze meg az eszköz leesését, mivel az komoly károkat okozhat.
3. Ne szerelje szét, javítsa meg vagy módosítsa a terméket egyedül. Meghibásodás esetén lépjen kapcsolatba egy jogosult szakemberrel.
4. A kockázatok elkerülése érdekében, megfelelő módon válassza meg a terméktől és ne dobja tűzbe, mivel beépített lítium akkumulátorral rendelkezik.
5. Az eszközt száraz ruhával tisztítsa.
6. Ne helyezze az eszközt hőforrások közelébe, ne tegye ki direkt napfénynek.
7. Ne helyezzen fém tárgyat az eszközbe, mivel rövidzárlatot okozhat.
8. A fülhallgató és fejhallgató magas hangerőn való használata maradandó halláskárosodáshoz vezethet.
9. Tartsa távol gyerekektől.

Ez a termék az alábbi irányelveknek felel meg:
RoHS 2.0 2011/65/EU irányelv és későbbi módosításai (EU) 2015/863
Rádióberendezésekről szóló irányelv (RED) – 2014/53/EU

Ez a szimbólum azt jelenti, hogy az eszköz elektromos élettartamának lejártja után az Ön háztartási hulladékaént elkülönítetten kell újrahasznosítani. Ennek megfelelően dobja a kijelölt hulladékgyűjtőbe. További információkért hívja a helyi hatóságokat.

Forgalmazó: Cool Collection,
1476 Budapest, Pf: 176. Magyarország
Cégjegyzékszám: 01-09-276783
Előgyártási ország: Kína


BACK PART

AP723199-10 Headphones Helton User manual



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specifications:

- Bluetooth 5.3
- Operating distance: Up to 10 meters
- Frequency: 20Hz-20KHz
- Impedance: 50ohms
- SNR: >85dB
- Distortion: less than 5%
- Lithium polymer battery 250mAh
- Charging voltage: 5V
- Working Time: 5-6h
- Charging Time: 1-2h
- Compatible with HFP/AVRCP/A2DP
- Charging cable included

Charging:

Charging station

Connect the device to a suitable power supply using the supplied cable.

During charging the red indicator light will stay on. When the charging station is fully charged the indicator light will change to blue.

Operation:

Press and hold the multifunction button to power on the headphone until the indicator light start flashing in red and blue colour. This indicates that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "1960" to pair. Once they are paired successfully, the light indicators will flash slowly.

Press and hold the multifunction button on one of the earphones for aprox. 5 seconds to turn off the device.

Play music from a SD card

Once the headphones power on, insert a micro SD card into the slot, and the headphones will start to play music automatically.

Controls:

Answer/End call:

Short press the multifunction button.

Reject call:

Long press the multifunction button.

Change mode (Bluetooth/SD card):

Press twice the multifunction button to change mode.

Play/Pause music:

Short press the multifunction button.

Next/previous Track:

To go to next track, keep pressed the button +.
To go to previous track, proceed in the same way button -.

Increase/decrease volume:

Press button + to increase volume (You'll heard a confirmation sound once you reach maximum level). To decrease make the sam way in the button -.

Voice assistant:

Press for a second the multifunction button to start the voice assistant previously configured in your smartphone.

Troubleshooting

Fault	Solution
Unable to pair up with other devices.	1. Check whether the earphone is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices.
The sound is low or distorted.	4. Check the Bluetooth device's volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the earphone effective transmission range is exceeded or if there is an obstacle standing between the earphone and other Bluetooth devices.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Excessive sound pressure from earphones and headphones can cause hearing loss.
9. Keep out of reach of children.

This item is in conformity with the following standards:
RoHS Directive 2011/65/EU and its subsequent amendments Directive (EU) 2015/863 Radio Equipment Directive (RED) - Directive 2014/53/EU

This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Distributor: Cool Collection,
1476 Budapest, Pf: 176. Hungary
Registration nr.: 01-09-276783
Made in China