









AP722102-01 VOLPUX RCS bluetooth fülhallgató

FRONT PART

<p>AP722102-01 Volpux RCS bluetooth fülhallgató Használati utasítás</p>   <p>Javasoljuk, hogy figyelmesen olvassa el ezt a használati utasítást és tartsa meg a jövőbeli felhasználáshoz!</p>	<p>Termék áttekintése:</p>  <p>Jellemzők:</p> <ul style="list-style-type: none">• 5.0 bluetooth verzió• Hatótávolság: akár 10 méter• Frekvencia: 20Hz – 20KHz• Fülhallgatók: Litium polimer akkumulátor 35mAh• Töltőállomás: Litium polimer akkumulátor 200mAh• Töltési feszültség: 5V• Munkaidő: 2,5 óra• Hangerő: 70dB• Ellenállás: 32ohm• Torzítás: kevesebb mint 5%• Kompatibilis: A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/DI1.3• Töltőkábel mellékelve	<p>Töltés: Töltőállomás: A töltéshez a mellékelt kábelt használja. Csatlakoztassa az USB kábelt a számítógéphez/AC adapterhez, a kábel másik végét csatlakoztassa a töltőállomás töltő portjához. A kijelző mutatja az eszköz akkumulátorának töltöttségi százalékát.</p> <p>Figyelem: ha a fülhallgatók a töltés során a töltőállomáson vannak, akkor azok is töltődnek egyidejűleg.</p> <p>Fülhallgatók: Tegye a fülhallgatókat a töltőállomásra és a töltési folyamat automatikusan megkezdődik. A töltés során a piros fény világít. Amikor a fülhallgatók teljesen feltöltődtek, a jelzőlámpa kialszik</p> <p>Működés: Egy vagy mindkét fülhallgatót használhatja egyszerre.</p> <p>Figyelem: ha eltávolítja a fülhallgatót a töltőállomásról, az automatikusan szinkronizálódik. Ha ki van kapcsolva és nincs a töltőállomáson, akkor az alábbi utasításokat kövesse:</p>	<p>Szimpla szinkronizálás: tartsa a fülhallgató multifunkciós gombját bekapcsolva, amíg a kék fény elkezd villogni. Ez jelzi azt, hogy az eszköz kész a párosításra.</p> <p>Az Ön eszközeinek bluetooth menüjéből válassza ki az új eszközök közül a „1149”-et a párosításhoz. Amikor sikeresen megtörtént a párosítás, a jelzőlámpa kikapcsol</p> <p>Dupla szinkronizálás: tartsa mindkét fülhallgató multifunkciós gombját bekapcsolva, amíg a piros és a kék fény a jobb oldali fülhallgatón elkezd villogni.</p> <p>Az Ön eszközeinek bluetooth menüjéből válassza ki az új eszközök közül a „1149”-et a párosításhoz. Amikor sikeresen megtörtént a párosítás, a jelzőlámpa a bal fülhallgatót kikapcsol.</p> <p>Figyelem: mindkét fülhallgató multifunkciós gombját tartsa benyomva az eszköz kikapcsolásához.</p>	<p>Vezérlések: Válasz/Hívás vége: nyomja meg bármelyik fülhallgató multifunkciós gombját röviden.</p> <p>Hívás elutasítása: nyomja meg bármelyik fülhallgató multifunkciós gombját hosszan.</p> <p>Zene leállítás/szüneteltetése: nyomja meg bármelyik fülhallgató multifunkciós gombját röviden.</p> <p>Következő/előző szám: szimpla/dupla szinkronizálás: A következő számhoz nyomja meg 3-szor a jobb fülhallgató multifunkciós gombját. Az előző számhoz nyomja meg 3-szor a bal fülhallgató multifunkciós gombját.</p> <p>Hangerő: a hangerő csökkentéséhez nyomja meg 2-szer a bal fülhallgató multifunkciós gombját. A hangerő növeléséhez nyomja meg 2-szer a jobb fülhallgató multifunkciós gombját</p>	<p>Hibaelhárítás:</p> <table border="1"><thead><tr><th>Hiba</th><th>Megoldás</th></tr></thead><tbody><tr><td>Nem képes kapcsolódni más eszközzel .</td><td>1. Ellenőrizze hogy a hangszóró még keresi-e a kapcsolatot vagy kapcsolja ki és be a készüléket. 2. Túl sok bluetooth eszköz van a közelben és ez okozza a problémát a kapcsolódásban. Kapcsolja ki a többi bluetooth eszközt. 3. Ellenőrizze hogy az Ön fülhallgatója „kapcsolódási üzemmódban” van-e.</td></tr><tr><td>A zene halk vagy torz .</td><td>4. Ellenőrizze a bluetooth hangerejének beállítását és állítsa be a megfelelő szintre. 5. Töltse fel az akkumulátort</td></tr><tr><td>Néha leáll a zene</td><td>6. Ellenőrizze le, hogy a hangszóró nem lépte-e túl a hatékony átviteli tartományt vagy nincs-e a hangszóró és a másik bluetooth eszköz között álló akadály.</td></tr></tbody></table>	Hiba	Megoldás	Nem képes kapcsolódni más eszközzel .	1. Ellenőrizze hogy a hangszóró még keresi-e a kapcsolatot vagy kapcsolja ki és be a készüléket. 2. Túl sok bluetooth eszköz van a közelben és ez okozza a problémát a kapcsolódásban. Kapcsolja ki a többi bluetooth eszközt. 3. Ellenőrizze hogy az Ön fülhallgatója „kapcsolódási üzemmódban” van-e.	A zene halk vagy torz .	4. Ellenőrizze a bluetooth hangerejének beállítását és állítsa be a megfelelő szintre. 5. Töltse fel az akkumulátort	Néha leáll a zene	6. Ellenőrizze le, hogy a hangszóró nem lépte-e túl a hatékony átviteli tartományt vagy nincs-e a hangszóró és a másik bluetooth eszköz között álló akadály.	<p>Figyelmeztetések:</p> <ol style="list-style-type: none">1. Ne tegye ki az eszközt esőnek vagy nyirkos környezetnek.2. Előzze meg, hogy az eszköz leessen, mert az komoly sérüléseket okozhat.3. Ne szedje szét, ne javítsa és ne alakítsa át az eszközt önállóan, lépjen kapcsolatba szakemberrel.4. Hogy minden kockázatot elkerüljön, ne dobja az eszközt helytelen szemetesbe, mert beépített lítium-akkumulátor van benne.5. Száraz ruhával takarítsa az eszközt.6. Ne tegye az eszközt közvetlen hőforrás mellé vagy közvetlen napsugárzásnak.7. Ne tegyen semmiféle fém eszközt a készülékbe, mert rövidzárlatot okozhat.8. A fülhallgató vagy fejhallgató túlzott hangnyomása a hallás elvesztését okozhatja.9. Gyermekek elől elzárva tartandó. <p>Ez a termék az alábbi irányelveknek felel meg:</p> <ul style="list-style-type: none">• RoHS 2.0 2011/65/EU irányelv és későbbi módosításai (EU) 2015/863• Rádióberendezésekről szóló irányelv (RED) – 2014/53/EU  <p>Ez a szimbólum a termékben és a használati útmutatóban is azt jelzi, hogy a készülék elektromos életciklusának végén a háztartási hulladéktól elkülönítve kell újrahasznosítani. Megfelelő eszközök általánosan rendelkezésre vannak az anyagok a megsemmisítésre – a megfelelő újrahasznosítás érdekében. További információért forduljon a helyi hatóságokhoz.</p> <p>VIGYÁZAT: Nem megfelelő elem használata esetén robbanásveszély áll fenn. Az elhasznált elemeket az utasításoknak megfelelően ártalmatlanítsa.</p> <p>CE RoHS</p> <p>Forgalmazó: Cool collection, Budapest FI-176, 1476, Magyarország Cégjegyzékszám: 01-09-276783 Szállás ország: Kína</p>
Hiba	Megoldás													
Nem képes kapcsolódni más eszközzel .	1. Ellenőrizze hogy a hangszóró még keresi-e a kapcsolatot vagy kapcsolja ki és be a készüléket. 2. Túl sok bluetooth eszköz van a közelben és ez okozza a problémát a kapcsolódásban. Kapcsolja ki a többi bluetooth eszközt. 3. Ellenőrizze hogy az Ön fülhallgatója „kapcsolódási üzemmódban” van-e.													
A zene halk vagy torz .	4. Ellenőrizze a bluetooth hangerejének beállítását és állítsa be a megfelelő szintre. 5. Töltse fel az akkumulátort													
Néha leáll a zene	6. Ellenőrizze le, hogy a hangszóró nem lépte-e túl a hatékony átviteli tartományt vagy nincs-e a hangszóró és a másik bluetooth eszköz között álló akadály.													

BACK PART

<p>AP722102-01 Earphones Volpux RCS User manual</p>   <p>It is recommended to read this user manual carefully and keep it for future reference.</p>	<p>Product overview:</p>  <p>Specifications:</p> <ul style="list-style-type: none">• Bluetooth Version 5.0• Operating distance: Up to 10 meters• Frequency: 20Hz-20KHz• Earphones: Lithium polymer battery 35mAh• Charging station: Lithium polymer battery 200mAh• Charging voltage: 5V• Working Time: 2.5h• SNR: 70dB• Impedance: 32ohms• Distortion: less than 5%• Compatible with A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/DI1.3 ,• Charging cable included	<p>Charging: Charging station Use the cable provided for charging. Connect USB cable to computer / AC adapter and connect the other end of the cable into the charging port of the charging station. The screen will stay on showing the battery percentage on the device.</p> <p>Note: if the earphones are in the charging station, both will be charged at the same time.</p> <p>Earphones Place the earphones into the charging station and the charging process will start automatically. During charging the red indicator light will stay on. When the earphones are fully charged the indicator light will turn off.</p> <p>Operation: You can use one or both earphones at the same time.</p> <p>Note: When you remove the earbuds from the charging station they will synchronize automatically. If they are turned off and out of the charging station, follow the below instructions:</p>	<p>Simple synchronization Hold the multifunction button to power on the earphone until de there and blue indicator light start flashing. This indicates that the device is ready to be paired.</p> <p>From the Bluetooth menu of your device, search for new devices and select“1149”to pair. Once they are paired successfully, the light indicator will turn off.</p> <p>Double synchronization Hold the multifunction button to power on both earphones until the red and blue indicator light on right earphone start to flash.</p> <p>From the Bluetooth menu of your device, search for new devices and select“1149”to pair. Once they are paired successfully, the light indicator on left earphone will turn off.</p> <p>Note: Hold the multifunction button of each earphone to power off the device.</p>	<p>Controls: Answer/End call: Short press the multifunction button of any earphone.</p> <p>Reject call: Long press the multifunction button of any earphone.</p> <p>Play/Pause music: Short press the multifunction button of any earphone.</p> <p>Next/previous Track: -Simple / Double synchronization: To go to next track, press 3 times the multifunction button on the right earphone. To go to previous track, press 3 times the multifunction button on the left earphone.</p> <p>Volume: To decrease the volume, press 2 times the multifunction button on the left earphone. To increase the volume, press 2 times the multifunction button on the right earphone.</p>	<p>Troubleshooting</p> <table border="1"><thead><tr><th>Fault</th><th>Solution</th></tr></thead><tbody><tr><td>Unable to pair up with other devices.</td><td>1. Check whether the earphone is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphone is in “Pairing Mode”.</td></tr><tr><td>The sound is low or distorted.</td><td>4. Check the Bluetooth device’s volume and then adjust it to an appropriate level. 5. Recharge the battery.</td></tr><tr><td>Occasionally the music stops.</td><td>6. Check whether the earphone effective transmission range is exceeded or if there is an obstacle standing between the earphone and other Bluetooth devices.</td></tr></tbody></table>	Fault	Solution	Unable to pair up with other devices.	1. Check whether the earphone is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphone is in “Pairing Mode”.	The sound is low or distorted.	4. Check the Bluetooth device’s volume and then adjust it to an appropriate level. 5. Recharge the battery.	Occasionally the music stops.	6. Check whether the earphone effective transmission range is exceeded or if there is an obstacle standing between the earphone and other Bluetooth devices.	<p>Warnings:</p> <ol style="list-style-type: none">1. Do not expose this product to rain or damp conditions.2. Prevent this item from falling as it could cause serious damage.3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.4. In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.5. Clean it with a dry cloth.6. Do not place this item near sources of heat or expose to direct sunlight.7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.8. Excessive sound pressure from earphones and headphones can cause hearing loss.9. Keep out of reach of children. <p>This item is in conformity with the following standards:</p> <ul style="list-style-type: none">• RoHS Directive 2011/65/EU and its subsequent amendments Directive (EU) 2015/863• Radio Equipment Directive (RED) - Directive 2014/53/EU  <p>This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material - for proper recycling. For more information, contact your local authorities.</p> <p>CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.</p> <p>CE RoHS</p> <p>Distributor: Cool Collection, 1476, Budapest, PE:176, Hungary Company registration number: 01-09-276783, Made in China</p>
Fault	Solution													
Unable to pair up with other devices.	1. Check whether the earphone is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphone is in “Pairing Mode”.													
The sound is low or distorted.	4. Check the Bluetooth device’s volume and then adjust it to an appropriate level. 5. Recharge the battery.													
Occasionally the music stops.	6. Check whether the earphone effective transmission range is exceeded or if there is an obstacle standing between the earphone and other Bluetooth devices.													