

FRONT PART

AP721402-01 Molik Power Bank Earphones User manual



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Important Safety Precautions:

Before use please note the following safety precautions. Failure to comply may be dangerous and cause damage to your mobile electronic devices.

- The power bank unit contains an internal 5200mAh polymer lithium battery. Upon initial use or after a prolonged period of storage, fully charge the unit.
- The unit will reach its maximum performance after 2 or 3 full charging and discharging cycles.
- Using an incorrect power adaptor or USB cable could cause damage to both your mobile devices and the Power Bank.
- Do not submerge in water or expose to adverse weather conditions.

- Avoid dropping the device.
- Keep the device away from fire and high temperatures.
- Keep the device out of reach of children.
- Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
- In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
- Clean it with a dry cloth.
- Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
- Excessive sound pressure from earphones and headphones can cause hearing loss.

Specifications:

- Bluetooth Version 4.2
- Earphones: Lithium polymer battery 35mAh / 3.7V
- Charging voltage: 5V
- Working Time: 2h
- Charging Time: 2h
- SNR: 90dB
- Frequency: 2.4GHz
- Impedance: 32ohms
- Distortion: less than 1%

- Compatible with A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/DI1.3
- Charging cable included
- Capacity: 5200mAh (19,24Wh) / 3.7V - Lithium Polymer Battery.
- Input: case: 5V \leq 2A; earphone: 5V \leq 0.5A
- Output: case: 5V \leq 2A
- Wireless charger: 5W
- Battery Life: More than 500 charging cycles.
- Charge indicator: 4 LEDs
- Wireless charge indicator: 1 LED
- Suitable temperature range for use: 0-35°C

Wireless charge: Suitable for all mobile devices with Qi technology.

Charging:

Power Bank

Connect USB cable to computer / AC adapter and connect the other end of the cable into the charging port of the charging station.

During the charging process of the power bank, the blue indicators light will start to flash. As the charging process is completing the lights will start to remain solid.

Note: If the earphones are in the charging station, both will be charge at the same time.

Earphones

Place the earphones into the charging station.

During charging the indicator light of the earphones will turn red. When the earphones are fully charged the indicator light will turn off.

Power Bank operation:

Connect the USB cable to the mobile device and connect the other end of the USB cable to the (out) port of the portable charger. When a mobile device is connected to the power bank the indicator lights will appear, according to the charge level available on the unit. During the charge transmission, the power of the portable charging device will decrease and the lights on the charge indicator will start to disappear indicating the remaining charge capacity available. Every light represents 25% of the total charge.

Wireless Charge operation:

To use the Wireless charger, press the ON/OFF button and place your Qi compatible device on top of the wireless charger, ensuring that it is centrally positioned.

When it is charging correctly a red light indicator will light up.

Note: If your phone has a protective case you may need to remove it for a successful connection. Cable and wireless charging can be used at the same time.

Earphones operation:

You can use one or both earphones at the same time.

Simple synchronization

Hold the multifunction button to power on the earphone until the red and blue indicator light starts flashing. This indicates that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "AP721402" to pair. Once they are paired successfully, the light indicator will turn off.

Controls:

Answer/End call:
Short press the multifunction button.

Reject call:
Long press the multifunction button.

Play/Pause music:

Short press the multifunction button.

Next Track: Press the multifunction button twice consecutively.

Double synchronization

Note: Only for the first connection. For future connections, the earphones will be synchronized automatically.

Hold the multifunction button to power on both earphones at the same time until the blue and red indicator light starts flashing. This indicates that the devices are ready to be paired.

Press twice the multifunction button on one of the earphones to enter synchronization mode.

Once synchronized, the red and blue indicator light on the right earphone will continue flashing, while on the other earphone, the indicator light in blue color will flash every 5 seconds. This indicates that both earphones have been synchronized correctly.

From the Bluetooth menu of your device, search for new devices and select "AP721402" to pair. Once they are paired successfully, the blue light indicator will turn off on both earphones.

Hold the multifunction button, on any of the earphones to power off the device.

Controls:

Answer/End call:
Short press the multifunction button of any earphone.

Reject call: Long press the multifunction button of any earphone.

Play/Pause music:
Short press the multifunction button of any earphone.

Next/Previous Track: Press the multifunction button twice on the left earbud to previous track. Press the multifunction button twice on the right earbud to go to next track.

Note: The volume must be adjusted from your mobile device.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Troubleshooting:

Fault	Solution
Unable to pair up with other devices.	1. Check whether the earphone is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices. 3. Make sure your earphone is in "Pairing Mode".
The sound is low or distorted.	4. Check the Bluetooth device's volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the earphone effective transmission range is exceeded or if there is an obstacle standing between the earphone and other Bluetooth devices.

This item is in conformity with the following standards:

Low Voltage Directive (LVD) - Directive 2014/35/EU
Radio Equipment Directive (RED) - Directive 2014/53/EU
Electromagnetic Compatibility (EMC) - Directive 2014/30/EU
RoHS Directive 2011/65/EU (RoHS 2.0) and its subsequent amendments Directive (EU) 2015/863



This symbol both in the product and its user manual indicates that at the end of the device's electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Distributor: Cool Collection,
1476 Budapest, POB:176. Hungary
Registration nr.: 01-09-276783
Made in China

AP721402-01 Molik hordozható töltő és fülhallgató Használati útmutató



Javasoljuk, hogy alaposan olvassa el a használati útmutatót és őrizze meg későbbi felhasználás céljából.

Termék áttekintés:



Fontos biztonsági óvintézkedések:

Használat előtt vegye figyelembe a következő biztonsági óvintézkedéseket. Ezek elmulasztása veszélyes lehet és kárt tehet elektronikus eszközeiben.

- A power bank egység egy 5200 mAh-s lítium polimer akkumulátort tartalmaz. Első használatkor vagy hosszabb tárolás után teljesen töltsse fel az akkumulátort. Az eszköz 2-3 teljes töltési és merülési ciklus után éri el maximális teljesítményét
- Nem megfelelő hálózati adapter vagy USB kábel használata károsíthatja mind a mobilkészítőt, mind a power bank-et.
- Ne merítse vízbe és ne tegye ki semmilyen időjárási viszonyoknak az egységet.

- Kerülje a készülék leejtését.
- Tartsa távol a készüléket tűztől és magas hőmérsékletektől.
- Tartsa távol a készüléket gyermekektől.
- Ne szedje szét, szerelje vagy módosítsa a terméket ön maga, keresse fel egy specialistát.
- A kockázat elkerülése érdekében a kijelölt helyekre dobja ki a terméket. Semmiképp se dobja tűzbe, mivel beépített lítium akkumulátor van benne.
- Száraz törölkendővel tisztítsa.
- Ne helyezzen semmilyen fémtárgyat a készülékbe, mert fennáll annak a veszélye, hogy rövidzárlat keletkezik az egységben.
- A túlzott hangerő halláskárosodást okozhat.

Technikai adatok:

- Bluetooth 4.2 verzió
- Fülhallgatók: lítium polimer akkumulátor 35mAh / 3,7V
- Töltési feszültség: 5V
- Működési időtartam: 2h
- Töltési idő: 2h
- SNR: 90dB
- Frekvencia: 2.4GHz
- Ellenállás: 32ohm
- Torzítás: kevesebb mint 1%

- Kompatibilis: A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/DI1.3
- Töltőkábel mellékelve
- Töltőállomás: 5200mAh (19,24Wh) / 3,7V – Lítium polimer akkumulátor
- Bemenet: tok? 5V \equiv 2A; fülhallgató: 5V \equiv 0.5A
- Kimenet: tok? 5V \equiv 2A.
- Vezeték nélküli töltő: 5W
- Akkumulátor élettartam: több mint 500 töltési ciklus.
- Töltés mutató: 4 LED
- Vezetéknélküli töltés mutató: 1 LED
- Használatra megfelelő hőmérséklet tartomány: 0-35°C

Vezeték nélküli töltés: megfelelő minden Qi technológiát használó mobilkészítőkhez.

Töltés:

Power bank

Csatlakoztassa az USB kábelt a számítógéphez / AC adapterhez, a kábel másik végét pedig a töltőállomás töltőportjához.

A töltési folyamat közben a kék jelzőfény villogni kezd. Ahogy a töltési folyamat befejeződik, a jelzőfények folyamatosan világítanak.

Megjegyzés: Ha a fülhallgatók a töltőállomásban vannak, mindkettő egyszerre töltődik.

Fülhallgatók:

Helyezze a fülhallgatókat a töltőállomásba.

A töltési folyamat során a fülhallgatók jelzőfénye pirosra vált. Amikor a fülhallgatók teljesen feltöltődtek, a jelzőfény kialszik.

Power Bank működése:

Csatlakoztassa az USB kábelt a mobilkészítőkhez, a másik végét pedig a hordozható töltő (kimeneti) portjához. Amikor egy mobilkészítőt csatlakoztat a power bankhez a jelzőfények az egység töltöttségi szintjének megfelelően jelennek meg. A töltési ciklus közben a hordozható töltőkészülék teljesítménye csökken és a jelzőfények eltűnnek, jelezve a rendelkezésre álló töltési kapacitást. Minden jelzőfény a teljes töltöttség 25%-át jelenti.

Vezeték nélküli töltés:

A vezeték nélküli töltő használatához nyomja meg a Be/Ki kapcsoló gombot az egységen és helyezze a Qi kompatibilis eszközt a vezeték nélküli töltő tetejére, ügyelve arra, hogy középen legyen.

Ha megfelelően tölt egy vörös jelzőfény fog világítani.

Megjegyzés: Ha telefonon védőtok van, lehetséges, hogy el kell távolítania a sikeres csatlakozáshoz. A kábeles és vezeték nélküli töltés egyszerre használható.

Fülhallgató működés:

Használhatja egyidejűleg csak az egyik vagy mindkettő fülhallgatót.

Egyszerű szinkronizálás:

Tartsa lenyomva a multifunkciós gombot a fülhallgató bekapcsolásához, amíg a piros és kék jelzőfény villogni nem kezd. Ez jelzi, hogy a készülék készen áll a párosításra.

Az eszköze Bluetooth menüjében keressen új eszközöket és válassza az "AP721402"-t a párosításhoz. Amint sikeres a párosítás, a jelzőfény kialszik.

Vezérlés:

Hívás fogadása/ befejezése: nyomja meg röviden a multifunkciós gombot.

Hívás elutasítása: Nyomja meg hosszan a multifunkciós gombot.

Zene lejátszása/ szüneteltetése: nyomja meg röviden a multifunkciós gombot.

Következő zeneszám: nyomja meg a multifunkciós gombot kétszer egymás után.

Dupla szinkronizálás:

Megjegyzés: csak az első párosításnál. A jövőbeni párosítások a fülhallgató automatikusan szinkronizál.

Tartsa lenyomva a multifunkciós gombot mindkét fülhallgatón egy időben, ameddig a kék és piros jelzőfények villogni kezdenek. Ez jelzi, hogy a készülékek készek a párosításra.

Nyomja meg a multifunkciós gombot kétszer az egyik fülhallgatón, hogy belépjen a szinkronizációs módba.

Szinkronizálás után a kék és piros jelzőfények a jobb fülhallgatón továbbra is villognak, míg a másik fülhallgatón a kék jelzőfény 5 másodpercenként felvillan. Ez jelzi, hogy a szinkronizáció mindkét fülhallgatón megfelelő volt.

Az eszköze Bluetooth menüjében keressen új eszközöket és válassza az "AP721402"-t a párosításhoz. Amint sikeres a párosítás, a kék jelzőfény mindkét fülhallgatón kialszik.

Tartsa lenyomva a multifunkciós gombot bármelyik fülhallgatón, hogy kikapcsolja azokat.

Vezérlés:

Hívás fogadása/ befejezése: nyomja meg röviden a multifunkciós gombot bármelyik fülhallgatón.

Hívás elutasítása: Nyomja meg hosszan a multifunkciós gombot bármelyik fülhallgatón

Zene lejátszása/ szüneteltetése: nyomja meg röviden a multifunkciós gombot bármelyik fülhallgatón.

Következő/ előző zeneszám: Nyomja meg kétszer a bal fülhallgatón a multifunkciós gombot az előző zeneszámhoz. Nyomja meg kétszer a multifunkciós gombot a job fülhallgatón a következő zeneszámhoz.

Megjegyzés: A hangerőt a mobiltelefonjáról tudja állítani.

VIGYÁZAT: Nem megfelelő elem használata esetén robbanásveszély áll fenn. Az elhasznált elemeket az utasításoknak megfelelően ártalmatlanítsa.


Hibaelhárítás:

Hiba	Megoldás
Nem képes csatlakozni más eszközökhöz.	1. Ellenőrizze, hogy a fülhallgató keresési funkciója aktív állapotban van-e, vagy kapcsolja ki és újra be a készüléket. 2. Túl sok Bluetooth eszköz nehézséget okozhat a kapcsolódásban. Kapcsolja ki a többi Bluetooth eszközt. 3. Ellenőrizze, hogy a fülhallgató párosítási módban van.
A hang halk vagy torz.	4. Ellenőrizze a Bluetooth eszközén a hangerőt, majd állítsa a megfelelő szintre. 5. Töltsse fel újra az akkumulátort.
Esetenként a zene megáll.	6. Ellenőrizze, hogy a fülhallgató hatékony átviteli tartományt átlépte-e, vagy van-e akadály, ami fennáll a fülhallgató és a Bluetooth eszköz között.

Ez a termék az alábbi irányelveknek felel meg:

Kisfeszültségű irányelv (LVD) - 2014/35/EU
Rádióberendezésekről szóló irányelv (RED) - 2014/53/EU
Elektromágneses összeférhetőség (EMC)-2014/30/EU irányelv
RoHS 2.0 2011/65/EU és későbbi módosításai (EU) 2015/863



 Ez a szimbólum a termék csomagolásán és a használati útmutatóján jelzi, hogy a készülék élettartama lejártá után a szelektív gyűjtőbe kerüljön elkuiontva a háztartási hulladéktól. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információkért keresse a helyi hatóságot.

Forgalmazó: Cool Collection, 1476
Budapest, Pf:176, Magyarország
Céginformációszám: 01-09-276783
Szármaizási ország: Kína

BACK PART