


User manual



Product Overview:



1. Specifications:

- Bluetooth specifications: Bluetooth Version 3.0 + EDR.
- USB charging voltage: DC 5V.
- Rechargeable Lithium battery included.
- Operating distance: < 10M.
- Frequency: 150Hz – 20KHz.
- Sensitivity: 90db ± 2db.
- USB charging cable included.

2. Buttons / Outer appearance:

1. : To Power On /Off the speaker.
2. : Play / Pause.
3. : Call button: To Pick up / Hang up / Dial the last outgoing phone call.

4. : Next track / Volume up.
5. : Previous track / Volume down.
6. MIC: Serves as microphone during hands-free call
7. DC 5V port: To connect with USB cable to charge.

3. Functions:

Power On / Off:

Hold ON / OFF button to power on the speaker and hold ON/ OFF button again to power off the speaker.

Volume Up / Down:

Hold the button to adjust the volume to the desired level.

Bluetooth Pairing:

Before using the Bluetooth speaker, you must pair it with a Bluetooth enabled device.

1. When the speaker is powered on, it will enter Bluetooth mode, the Blue LED light will flash quickly.
2. From the Bluetooth menu of your device, search for new devices and select "4929" to pair with your device.
3. Once they are paired successfully, you will hear a confirmation sound.
4. If the speaker is turned off, the device and the speaker will need to

be reconnected.

Calls:

When there is an incoming call, press the call button () to pick up / hang up the phone call. Press the Call button twice to redial the last outgoing phone number. The speaker will voice out the phone numbers when receiving the calls.

Charging:

Insert the charging cable into the DC 5V Jack of the unit, connect the USB to a PC or AC /DC adapter to charge the speaker.

4. Troubleshooting.

| Fault | Solutions |
|---------------------------------------|--|
| Unable to pair up with other devices. | 1. Check whether the speaker is still in the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Please turn them off. |
| The sound is rather low or distorted. | 1. Check the Bluetooth device's volume and then adjust it to a n appropriate level. 2. Recharge the battery. |
| The music stops from time to time. | 1. Check whether the speaker's effective transmission range is exceeded or if there is an obstacle standing between the speaker and other Bluetooth devices. |
| The Bluetooth indicator remains off. | 1. The battery power may too low. Recharge the battery. 2. Turn device off and on again. |

5. Safety instructions / Precautions:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.



Made in PRC



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Distributor: Cool collection, Budapest,
POB:176, 1476, Hungary
Corporate registration nr: 01-09-276783