

AP734130 Oriley Earphones/ Fülhallgató

FRONT PART

AP734130 Oriley Earphones User manual



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specifications:

- Bluetooth 5.1+EDR
- Operating distance: Up to 10 meters
- Frequency: 20Hz-20KHz
- Impedance: 5ohms
- SNR: 93dB
- Distortion: less than 1%
- Charging station: Lithium polymer battery 200mAh
- Earphones: Lithium polymer battery 30mAh
- Charging voltage: 5V
- Working Time: 3-4h
- Charging Time: 1.5h
- Compatible with HSP1.2, HFP1.6, A2DP1.3, AVRCP1.5
- Charging cable included

Charging:

Charging station

Use the cable provided for charging. Connect USB cable to the suitable power supply and connect the other end of the cable into the charging port of the charging station.

During charging the red indicator light will flash. When the charging station is fully charged the indicator light will stay on.

Note: If the earphones are in the charging station, both will be charged at the same time.

Earphones

Place the earphones into the charging station and the charging process will start automatically. During charging the red indicators light will stay on. When the earphones are fully charged the indicators light will turn off.

Operation:

You can use one or both earphones at the same time. When you remove the earbuds from the charging station they will synchronize automatically.

If they are turned off, press and hold the multifunction button to power on the earphone until hears a confirmation sound. This indicates that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "21031" to pair. Once they are paired successfully, you will hear a confirmation sound.

Press and hold the multifunction button on one of the earphones for approx. 3 seconds to turn off the device.

Controls:

Answer/End call:

Short press the multifunction button of any earphone.

Reject call:

Long press the multifunction button of any earphone.

Play/Pause music:

Short press the multifunction button of any earphone.

Next/previous Track:

To go to next track, press twice the multifunction button on the right earphone. To go to previous track, proceed in the same way on the left earphone.

Increase/decrease volume:

Press three times the multifunction button on the right earphone to increase volume. Proceed in the same way on the left earphone to decrease volume.

Troubleshooting

Fault	Solution
Unable to pair up with other devices.	1. Check whether the earphone is still on the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. 3. Turn off other Bluetooth devices.
The sound is low or distorted.	4. Check the Bluetooth device's volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the earphone effective transmission range is exceeded or if there is an obstacle standing between the earphone and other Bluetooth devices.

This item is in conformity with the following standards:
RoHS Directive 2011/65/EU and its subsequent amendments
Directive (EU) 2015/863
Radio Equipment Directive (RED) - Directive 2014/53/EU

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately or throw it into the fire as there is a built-in Lithium battery.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Excessive sound pressure from earphones and headphones can cause hearing loss.
9. Keep out of reach of children.

This symbol both in the product and its user manual indicates that at the end of the device's electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

RoHS

Distributor: Cool Collection 1476, Budapest, POB:176, Hungary
Registration nr. 01-09-276783
Made in China

BACK PART

AP734130 Oriley Fülhallgató Használati útmutató



Javasoljuk, hogy figyelmesen olvassa el ezt a felhasználói kézikönyvet, és őrizze meg későbbi használatra.

Termék áttekintés:



Műszaki adatok:

- Bluetooth 5.1+EDR
- Működési távolság: 10 méterig
- Frekvencia: 20Hz-20KHz
- Ellenállás: 5ohms
- Hangerő: 93dB
- Torzítás: kevesebb mint 1%
- Töltőállomás: Lítium-polimer akkumulátor 200mAh
- Fülhallgató: Lítium-polimer akkumulátor 30mAh
- Töltési feszültség: 5V
- Működési idő: 3-4 óra
- Töltési idő: 1.5 óra
- Kompatibilis a HSP1.2, HFP1.6, A2DP1.3, AVRCP1.5 szabványokkal.
- Töltőkábel mellékelve

Töltés:

Töltőállomás

A töltéshez használja a mellékelt kábelt. Csatlakoztassa az USB-kábelt a megfelelő tápegységhez, és csatlakoztassa a kábel másik végét a töltőállomás töltőportjához.

Töltés közben a piros jelzőfény villogni fog. Amikor a töltőállomás teljesen feltöltődött, a jelzőfény világít.

Megjegyzés: Ha a fülhallgató a töltőállomásban van, mindkettő egyszerre töltődik.

Fülhallgatók

Helyezze a fülhallgatót a töltőállomásba, és a töltési folyamat automatikusan elindul.

A töltés alatt a piros jelzőfény világít. Amikor a fülhallgató teljesen feltöltődött, a jelzőfény kialszik.

Művelet:

Egyszerre használhatja az egyik vagy mindkét fülhallgatót. Amikor kivessi a fülhallgatókat a töltőállomásból, azok automatikusan szinkronizálódnak.

Ha ki vannak kapcsolva, nyomja meg és tartsa lenyomva a többfunkciós gombot a fülhallgató bekapcsolásához, amíg megerősítő hangot nem hall. Ez azt jelzi, hogy a készülék készen áll a párosításra.

A készülék Bluetooth menüjében keressen új eszközöket, és válassza ki a "21031"-et a párosításhoz. A sikeres párosítás után egy megerősítő hangot fog hallani.

A készülék kikapcsolásához nyomja meg és tartsa lenyomva az egyik fülhallgató multifunkciós gombját kb. 3 másodpercig.

Vezérlők:

Hívás fogadása/befejezése:

Nyomja meg röviden bármelyik fülhallgató többfunkciós gombját.

Hívás elutasítása:

Nyomja meg hosszan bármelyik fülhallgató többfunkciós gombját.

Zene lejátszása/szüneteltetése:

Nyomja meg röviden bármelyik fülhallgató többfunkciós gombját.

Következő/előző zeneszám:

A következő zeneszámra való áttéréshez nyomja meg kétszer a jobb fülhallgatón lévő többfunkciós gombot. Az előző zeneszámra való áttéréshez ugyanígy járjon el a bal fülhallgatóval.

Növeli/cökkenti a hangerőt:

A hangerő növeléséhez nyomja meg háromszor a jobb fülhallgatón lévő multifunkciós gombot. A hangerő csökkentéséhez ugyanígy járjon el a bal fülhallgatóval.

Hibaelhárítás

Hiba	Megoldás
Más eszközökkel való párosítás nem lehetséges	1. Ellenőrizze, hogy a fülhallgató még mindig a keresés folyamatában van-e, vagy kapcsolja ki és újra be. 2. Túl sok Bluetooth-eszköz van a közelben, ami diffíciteket okoz a csatlakozásban. 3. Kapcsolja ki a többi Bluetooth-eszközt.
A hang mély vagy torzított	4. Ellenőrizze a Bluetooth készülék hangerejét, majd állítsa be a megfelelő szintre. 5. Töltsse fel az akkumulátort.
Időnként megáll a zene.	6. Ellenőrizze, hogy nem lépte-e túl a fülhallgató hatékony átviteli tartományát, vagy nem áll-e akadály a fülhallgató és más Bluetooth-eszközök között.

Ez a termék az alábbi irányelveknek felel meg:
RoHS 2.0 2011/65/EU irányelv és későbbi módosításai (EU) 2015/863
Rádióberendezésekről szóló irányelv (RED) – 2014/53/EU

Figyelmeztetés:

1. Ne tegye ki ezt a terméket esőnek vagy nedves körülményeknek.
2. Ne engedje leesni ezt az elemet, mert súlyos károkat okozhat.
3. Ne szerelje szét, ne javítsa vagy módosítsa ezt a terméket saját maga, forduljon hivatalos szakemberhez.
4. A kockázatok elkerülése érdekében ne dobja el ezt a terméket nem megfelelő módon, és ne dobja tűzbe, mivel a készülékben lítium akkumulátor van beépítve.
5. Tisztítsa meg száraz ruhával.
6. Ne helyezze ezt a készüléket hőforrások közelébe, és ne tegye ki közvetlen napfénynek.
7. Ne helyezze fémtárgyakat a készülékbe, mert fennáll a veszélye, hogy rövidzárlatot okoz a készülékben.
8. A fülhallgatók és fejhallgatók túlzott hangnyomása halláskárosodást okozhat.
9. Gyermekek elől elzárva tartandó.

Ez a szimbólum mind a terméken, mind a használati útmutatóban jelzi, hogy a készülék elektronos életciklusának végén a háztartási hulladéktól elkülönítve kell újrahasznosítani. Megfelelő eszközök állnak rendelkezésre az anyag megfelelő újrahasznosítása érdekében történő ártalmatlanítására. További információért forduljon a helyi hatóságokhoz.

VIGYÁZAT: Nem megfelelő elem használata esetén robbanásveszély áll fenn. Az elhasznált elemeket az utasításoknak megfelelően ártalmatlanítsa.

RoHS

Forgalmazó: Cool Collection, 1476 Budapest, PF:176, Magyarország
Cégjegyzékszám: 01-09-276783
Számzási ország: Kína