

# AP721516\_Cayren speaker/Cayren bluetooth hangszóró

## AP721516\_Speaker Cayren User Manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

### Product Overview:



### Specifications:

- Bluetooth Version 5.0
- Charging voltage: 5V
- Lithium battery 300mAh 3.7V
- Working Time: 2-3h
- Operating distance: up to 10 meters
- Frequency: 100Hz-20KHz
- Impedance: 4ohms
- Power output: 3W
- SNR: 80dB

### Operation:

Switch ON/OFF button to "ON" position to power on the speaker. From the Bluetooth menu of your device, search for new devices and select "6540" to pair. Once they are paired successfully, you will hear a notification sound.

Switch ON/OFF button to "OFF" position to power off the speaker.

Note: volume and next/previous track must be controlled from your mobile device.

### Charging:

Use the cable provided for charging. Connect the USB cable to computer / AC adapter. Connect the micro USB end of this cable into the micro USB port of your device.

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

### Troubleshooting:

Fault	Solution
Unable to pair with other devices.	1. Check whether the speaker is still in the process of search or switch it off and on again. 2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices.
The sound is low or distorted.	4. Check the Bluetooth device volume and then adjust it to an appropriate level. 5. Recharge the battery.
Occasionally the music stops.	6. Check whether the speaker effective transmission range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.

### Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Distributor: Cool Collection, 1476, Budapest, POB:176, Hungary  
Registration nr.: 01-09-276783, Made in China

## AP721516\_Cayren bluetooth hangszóró



Javasoljuk, hogy alaposan olvassa el a használati útmutatót és őrizze meg későbbi felhasználás céljából.

### Termék áttekintés



### Technikai adatok:

- Bluetooth verzió 5.0
- Töltési feszültség: 5V
- Lithium akkumulátor 300mAh 3.7V
- Működési idő: 2-3 óra
- Működési távolság: 10 méterig
- Frekvencia: 100Hz -20KHz
- Ellenállás:4ohm
- Teljesítmény:3W
- THD:>5%
- SNR: 80dB

### Működés:

Nyomja hosszan a bekapcsoló gombot a hangszóró bekapcsolásához. A jelzőfény villogni kezd ami jelzi, hogy az eszköz párosításra kész állapotban van.

Eszközének Bluetooth menüjéből keresse meg és válassza ki a „6540” lehetőséget és csatlakoztassa. Sikeres csatlakoztatás esetén egy értesítési hangot fog hallani és a jelzőfény világítani fog.

Nyomja meg az "OFF" gombot a hangszóró kikapcsolásához.

Megjegyzés: A hangerő beállítása és a következő/előző műsorszám a mobilkészületről vezérelhető.

### Töltés:

Töltés esetén használja a termékhez mellékelt kábelt. Csatlakoztassa az USB kábelt számítógéphez vagy az AC adapterhez. Csatlakoztassa a kábel végét a készülék DC portjához.

Töltés közben a jelzőfény pirosan világít. Amikor a hangszóró teljesen feltöltött a jelzőfény kialszik.

### Hibaelhárítás

Fault	Solution
Nem tudja párosítani az eszközöket	1. Ellenőrizze, hogy a hangszóró keresés alatt áll-e vagy kapcsolja ki és be 2. Túl sok Bluetooth-eszköz van a közelben, amely csatlakozási nehézségeket okoz. 3. Győződjön meg arról, hogy a hangszóró párosítási módban van
Halk vagy torzult a zene	4. Ellenőrizze a Bluetooth eszközön a hangerőt és állítsa be a megfelelő hangerőt 5. Töltsé fel az akkumulátort
Leáll időnként a zene	6. Ellenőrizze, hogy nem haladja meg a hatótávolságot vagy van-e valami akadály a hangszóró és a Bluetooth eszköz között.

### Figyelmeztetés

1. Ne tegye ki a terméket esőnek vagy páras körülményeknek.
2. Akadályozza meg a termék leesését, mert az komoly kárt okozhat.
3. Ne szedje szét, javítsa-vagy módosítsa az eszközt magától, keresen fel egy szakembert.
4. A kockázatok elkerülése végett ne szabaduljon meg a terméktől helytelenül, mert beépített Litium akkumulátort tartalmaz.
5. Tisztítsa a hangszórót száraz törlőruhával.
6. Ne helyezze az eszközt hőforrás közelébe, - illetve ne tegye ki napfénynek.
7. Ne helyezzen semmilyen fém tárgyat az eszközbe, mert az rövidzárlatot okozhat.
8. Gyermekektől távol tartandó.



Ez a szimbólum a termék csomagolásán és a használati útmutatóján jelzi, hogy a készülék élettartama lejártá után a selektív gyűjtőbe kerüljön elkülönítve a háztartási hulladéktól. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információkért keresse a helyi hatóságát.

Forgalmazó: Cool Collection, 1476, Budapest, Pf:176, Magyarország  
Céggjegyzékszám: 01-09-276783, Származási ország: Kína