

AP722280-77_Donny RPET bluetooth hangszóró

FRONT PART

AP722280-77_Donny RPET bluetooth hangszóró Használati útmutató (Hun)



Javasoljuk, hogy alaposan olvassa el a használati útmutatót és őrizze meg későbbi felhasználás céljából!

Termék nézet:



Jellemzők:

Bluetooth verzió: 5.0
Töltési feszültség: 5V
Lítium akkumulátor: 300mAh, 3.7V
Működési idő: 2-3h
Hatótáv: 10 méterig
Frekvencia: 280Hz-16KHz
Impedancia: 40ohms
Kimeneti energia: 3W
SNR: 95dB

Működtetés:

Nyomd hosszan az ON/OFF gombot, hogy bekapcsold a hangszórót.

Az eszközén Bluetooth-on keresztül válassza ki a "1192" nevűt, és csatlakoztassa. Amint csatlakozott az eszköz jelzőhangot ad ki és a jelzőfény bekapcsolva marad.

Nyomja hosszan az ON/OFF gombot, hogy kikapcsolja az eszközt.

Megjegyzés: Hangerőt és előre, hátra léptetést csak a mobil eszközén keresztül tud végezni.

Töltés:

Használja az eszközhöz biztosított kábelt a töltéshez. Csatlakoztassa az USB kábelt a számítógépéhez, vagy hálózati adapterhez. Csatlakoztassa a Mikro USB kábel végét a mikro USB porthoz az eszközén.

A töltési folyamat közben piros jelzőfény marad világítva. Amikor a hangszóró teljesen feltöltődött, a jelzőfény kikapcsol.

Hibaelhárítás:

Hiba	Megoldás
Nem sikerül párosítani az eszközöket.	<ul style="list-style-type: none">Ellenőrizze, hogy a hangszóró valóban keresi az eszközt, kapcsolja ki, majd újra be.Túl sok Bluetooth eszköz van a közelben, ami megnehezíti a kapcsolódást. Kapcsolja ki a többi Bluetooth eszközöket.
A hang halk vagy torz.	<ul style="list-style-type: none">Ellenőrizze a Bluetooth eszköz erősségét, állítsa a megfelelő szintre.Cserélje ki az elemet.
Esetenként a lejátszás megáll.	<ul style="list-style-type: none">Ellenőrizze, hogy az átvétel elég hatékony-e, hatótávon kívülre került-e az eszköz, vagy van-e akadály a hangszóró és a Bluetooth eszköz között.

Figyelmeztetések:

- Ne tegye ki az eszközt esőnek vagy nyirkos környezetnek.
- Előzze meg, hogy az eszköz leessen, mert az komoly sérüléseket okozhat.
- Ne szedje szét, ne javítsa és ne alakítsa át az eszközt önállóan, lépjen kapcsolatba szakemberrel.
- Hogy minden kockázatot elkerüljön, ne dobja az eszközt helytelen szemetesbe.
- Száraz ruhával takarítsa az eszközt.
- Ne tegye az eszközt közvetlen hőforrás mellé vagy közvetlen napsugárzásnak.
- Ne tegyen semmilyen fém eszközt a készülékbe, mert rövidzárlatot okozhat.
- Gyermekektől tartsa elzárva.



Ez a szimbólum azt jelenti, hogy az eszköz elektromos élettartamának lejártá után az Ön háztartási hulladéktól elkülönítetten kell újrahasznosítani. Ennek megfelelően dobja a kijelölt hulladékgyűjtőbe. További információkért hívja a helyi hatóságokat.



MADE IN PRC

Cikkszám: AP722280-77
Forgalmazó: Cool collection, Budapest
Pf.:176, 1476, Magyarország
Cégjegyzékszám: 01-09-276783
Származási ország: Kína

BACK PART

AP722280-77_Speaker Donny User Manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product Overview:



Specifications:

Bluetooth Version 5.0
Charging voltage: 5V
Lithium battery 300mAh 3.7V
Working Time: 2-3h
Operating distance: up to 10 meters
Frequency: 280Hz-16KHz
Impedance: 40ohms
Power output: 3W
SNR: 95dB

Operation:

Long press the ON/OFF button to power on the speaker.

From the Bluetooth menu of your device, search for new devices and select "1192" to pair. Once they are paired successfully, you will hear a notification sound and the indicator light will remain on.

Long press the ON/OFF button to power off the speaker.

Note: volume and next/previous track must be controlled from your mobile device.

Charging:

Use the cable provided for charging. Connect the USB cable to computer / AC adapter. Connect the micro USB end of this cable into the micro USB port of your device.

During charging, the red indicator light will stay on. When the speaker is fully charged the indicator light will turn off.

Troubleshooting:

Fault	Solution
Unable to pair with other devices.	<ol style="list-style-type: none">1. Check whether the speaker is still in the process of search or switch it off and on again.2. There are too many Bluetooth devices in the proximity, thus cause difficulty in connection. Turn off other Bluetooth devices.
The sound is lower or distorted.	<ol style="list-style-type: none">4. Check the Bluetooth device volume and then adjust it to an appropriate level.5. Recharge the battery.
Occasionally the music stops.	<ol style="list-style-type: none">6. Check whether the speaker's effective transmission range is exceeded or if there is an obstacle between the speaker and other Bluetooth devices.

Warnings:

1. Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately as there is a built-in Lithium battery.
5. Clean the speaker with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.
8. Keep out of reach of children.



This symbol both in the product and its user manual indicates that at the end of the device's electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.



MADE IN PRC

Cikkszám: AP722280-77
Forgalmazó: Cool collection, Budapest Pf.:176,
1476, Magyarország
Cégjegyzékszám: 01-09-276783
Származási ország: Kína