

# AP781600\_Tresor Heaphones /Tresor fejhallgató

## BACK PART

### AP781600\_Heaphones Tresor User Manual (eng)



It is recommended to read this user manual carefully and keep it for future reference.

#### Product Overview:



#### Specifications:

- Bluetooth Version 5.0
- Output: 10mW
- Operating distance: up to 10 meters
- Frequency: 20Hz-20KHz
- SNR: 95dB
- Impedance: 32ohms
- Distortion: less than 1%
- Lithium battery 300mAh
- Input: 3.7V
- Working Time: 6-7h
- Standby time: Up to 180h
- Micro USB cable
- Audio cable Jack 3.5 mm

#### Charging:

Use the cable provided for charging. Connect USB cable to computer / AC adapter. Connect the micro USB end of this cable into the micro USB port of your device.

During charging the indicator light will turn red. When the headphones are fully charged the red indicator light changes to blue.

IMPORTANT: Charge the device when is turned off.

#### Operation:

Hold the button to power on the headphones. The red and blue indicator light will flash to indicate that the device is ready to be paired.

From the Bluetooth menu of your device, search for new devices and select "5562" to pair. Once they are paired successfully, the blue indicator light will stay on. The light indicators will continue to flash while using some of the functions.

Hold the button to power off the headphones.

#### Audio Input (Line in):

Insert the audio cable 3.5mm into the headphones, and connect the other end of the audio cable into your mp3 / mp4 player / mobile phone or other compatible device to play your music.

Note: To use this function, the headphones must be turned off.

#### Controls:

	<ul style="list-style-type: none"> <li>• Short-press the button to next song.</li> <li>• Long-press the button to VOL +. (a sound indicates maximum volume)</li> </ul>
	<ul style="list-style-type: none"> <li>• Short-press the button to previous song.</li> <li>• Long-press the button to VOL -. (a sound indicates minimum volume)</li> </ul>
	<ul style="list-style-type: none"> <li>• Short-press the button to answer/end a call.</li> <li>• Short-press the button to play/pause the music.</li> <li>• Long-press the button to reject an incoming call.</li> <li>• Press the button twice to redial the last outgoing phone number.</li> </ul>

#### Troubleshooting:

Fault	Solutions
Unable to pair up with other devices.	<ol style="list-style-type: none"> <li>1. Check whether the earphones are still on the process of search or switch them off and on again.</li> <li>2. There are too many Bluetooth devices in the proximity that cause difficulty in connection. Turn off other Bluetooth devices.</li> <li>3. Make sure your earphones are in "Pairing Mode".</li> </ol>
The sound is low or distorted.	<ol style="list-style-type: none"> <li>4. Check the Bluetooth device's volume and then adjust it to an appropriate level.</li> <li>5. Recharge the battery.</li> </ol>
Occasionally the music stops.	<ol style="list-style-type: none"> <li>6. Check whether the earphones effective transmission range is exceeded or if there is an obstacle standing between the earphones and other Bluetooth devices.</li> </ol>



MADE IN PRC

This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities.

Distributor: Cool Collection, 1476, Budapest, POB:176, Hungary  
Registration nr.: 01-09-276783, Made in China

## BACK PART

### AP781600 Tresor fejhallgató Használati útmutató



Javasoljuk, hogy alaposan olvassa el a használati útmutatót és őrizze meg későbbi felhasználás céljából!

#### Termék áttekintés:



#### Technikai adatok:

- 4.2 + EDR Bluetooth
- 10mW kimenet
- Hatótávolság: akár 10 méter
- Frekvencia: 20-20KHz
- Hangerő: 95dB
- Ellenállás: 32 Ohm
- Torzítás: kevesebb mint 1%
- Lítium akkumulátor 300mAh
- Bemenet: 3,7V
- Működési időtartam: 6-7 óra
- Készenléti idő: 180 óra
- Mikro USB kábel
- 3.5 mm Jack audio kábel

#### Töltés:

Töltés esetén használja a termékhez mellékelt kábelt. Csatlakoztassa az USB kábelt a számítógéphez / AC adapterhez. Csatlakoztassa a kábel Mikro USB végét a készülékének Mikro USB portjához.

A töltés alatt a jelzőfény pirosra vált. Teljesen feltöltött állapotban a piros jelzőfény kékre vált.

Fontos: A készüléket csak kikapcsolt állapotban töltsé.

#### Működtetés:

Tartsa lenyomva a gombot a fejhallgató bekapcsolásához. A kék és piros fény kivillanása jelzi, ha az eszköz kész a párosításra.

Az eszköz Bluetooth menüjében keressen új eszközöket és válassza a(z) "5562"-t a párosításhoz. Amint sikeres a csatlakozás, a jelzőfény folyamatosan kéken fog világítani. A visszajelző fények villogni fognak néhány funkció használatá közben.

Tartsa lenyomva a gombot a készülék kikapcsolásához

#### Audio bemenet:

Helyezze a 3.5 mm-es kábelt a fejhallgatóba, és csatlakoztassa a másik végét az MP3 / MP4 lejátszó / mobiltelefonhoz vagy más kompatibilis eszközhöz a zene lejátszásához.

Megjegyzés: A funkció használatához a fejhallgatót ki kell kapcsolni.

#### Vezérlés

	<ul style="list-style-type: none"> <li>-Nyomja meg röviden a gombot a következő szám kiválasztásához.</li> <li>-Nyomja meg hosszan a gombot a hangerő növeléséhez. (egy hang fogja jelezni a maximális hangerőt)</li> </ul>
	<ul style="list-style-type: none"> <li>-Nyomja meg röviden a gombot az előző zeneszámmhoz.</li> <li>-Nyomja meg hosszan a gombot a hangerő csökkentéséhez. (egy hang fogja jelezni a minimális hangerőt)</li> </ul>
	<ul style="list-style-type: none"> <li>-Nyomja meg röviden a gombot bejövő hívás fogadásához.</li> <li>-Nyomja meg röviden a gombot a zene lejátszásához / szüneteltetéséhez.</li> <li>-Nyomja meg hosszan a gombot bejövő hívás elutasításához.</li> <li>-Nyomja meg kétszer a gombot az utolsó kimenő hívás újratárcsázásához.</li> </ul>

#### Troubleshooting:

Probléma	Megoldás
Nem tud kapcsolódni más eszközökhöz.	<ol style="list-style-type: none"> <li>1. Ellenőrizze, hogy a fejhallgató még mindig keresi-e a készüléket, vagy kapcsolja ki és újra be az.</li> <li>2. Problémát okozhat a csatlakozásban, ha több Bluetooth eszköz található a közelében. Kapcsolja ki a többi Bluetooth eszközt.</li> <li>3. Bizonyosodjon meg arról, hogy az eszköz párosítási módban van.</li> </ol>
A hang halk vagy torz.	<ol style="list-style-type: none"> <li>4. Ellenőrizze a Bluetooth eszközön a hangerőt, majd állítsa be a kívánt szintre.</li> <li>5. Töltsé fel az akkumulátort.</li> </ol>
Időnként a zene megáll.	<ol style="list-style-type: none"> <li>6. Ellenőrizze, hogy túllépte-e a fejhallgató tényleges átviteli tartományát, illetve, hogy van-e akadály a fejhallgató és más Bluetooth-eszközök között.</li> </ol>



MADE IN PRC

Ez a szimbólum a termék csomagolásán és a használati útmutatóján jelzi, hogy a készülék életartama lejártá után a szkektív gyűjtőbe kerüljön elkülönítve a háztartási hulladéktól. Ez a jel gondoskodik az alapanyag megfelelő újrahasznosításáról. További információkért keresse a helyi hatóságot.

Forgalmazó: Cool Collection, 1476, Budapest, PE176, Magyarország  
Céggjegyzékszám: 01-09-276783, Származási ország: Kína